






Operation and Maintenance Manual C Series Engines

U.S.A., Canada, Australia,
New Zealand, and Puerto Rico



Cummins Engine Company, Inc.
Box 3005
Columbus, Indiana, U.S.A., 47202
Cable: CUMDIEX COLUMBUS


Registered Office
Cummins Engine Company, Ltd.
46-50 Coombe Road
New Malden,
Surrey KT3 4QL,
England
Cable: CUMEUR G
Registration No. 573951 England

Copyright © 1991
Cummins Engine Company, Inc.



Operation and Maintenance Manual C Series Engines

U.S.A., Canada, Australia,
New Zealand, and Puerto Rico



Copyright © 1993
Cummins Engine Company, Inc.
All rights reserved

Bulletin No. 3810248-08
Printed 6/93


Foreword

This manual contains information for the correct operation and maintenance of your Cummins engine. It also includes important safety information, engine and systems specifications, troubleshooting guidelines, and listings of Cummins Authorized Repair Locations and component manufacturers.

Keep this manual with the equipment. If the equipment is traded or sold, give the manual to the new owner.

The information, specifications, and recommended maintenance guidelines in this manual are based on information in effect at the time of printing. Cummins Engine Company, Inc. reserves the right to make changes at any time without obligation. If you find differences between your engine and the information in this manual, contact your local Cummins Authorized Repair Location.

The latest technology and the highest quality components were used to produce this engine. When replacement parts are needed, we recommend using only genuine Cummins or ReCon® exchange parts. These parts can be identified by the following trademarks:



Note: Warranty information is located in Section W. Make sure you are familiar with the warranty or warranties applicable to your engine.

Table of Contents

	Page No.
Introduction	i
Engine Identification	E
Operating Instructions	1
Maintenance Guidelines	2
Daily Maintenance Procedures	3
Maintenance Procedures at 10,000 Kilometers [6,000 Miles] 250 Hours or 3 Months	4
Maintenance Procedures at 19,000 Kilometers [12,000 Miles]	5
Maintenance Procedures at 38,000 Kilometers [24,000 Miles] 1000 Hours or 12 Months	6
Maintenance Procedures at 77,000 Kilometers [48,000 Miles] 2000 Hours or 2 Years	7
System Diagrams	D
Troubleshooting	T

	Page No.
Adjustment, Repair and Replacement	A
Specifications and Torque Values	V
Service Assistance	S
Component Manufacturers	C
Warranty	W
Literature	L
Index	X

Section i - Introduction

Section Contents

	Page
About the Manual.....	i-3
Definition of Terms.....	i-12
General Safety Instructions	i-10
Important Safety Notice	i-10
How to Use the Manual.....	i-4
Illustrations	i-9
Symbols	i-5
To The Owner and Operator	i-2

About the Manual

This manual contains information needed to correctly operate and maintain your engine as recommended by Cummins Engine Company, Inc. Additional service literature (Shop Manual, Troubleshooting and Repair Manual, etc.) can be ordered by filling out and mailing the Literature Order Form located in Service Literature, Section L.

This manual does **not** cover vehicle or equipment maintenance procedures. Consult the vehicle or equipment manufacturer for specific maintenance recommendations.

Both metric and U.S. customary values are listed in this manual. The metric value is listed first, followed by the U.S. customary in brackets.

Numerous illustrations and symbols are used to aid in understanding the meaning of the text. Refer to page i-5 for a complete listing of symbols and their definitions.

Each section is preceded by a "Section Contents" to aid in locating information more quickly.

Symbols

The following symbols have been used in this manual to help communicate the intent of the instructions. When one of the symbols appears, it conveys the meaning defined below:



WARNING - Serious personal injury or extensive property damage can result if the warning instructions are **not** followed.



CAUTION - Minor personal injury can result or a part, an assembly, or the engine can be damaged if the caution instructions are **not** followed.



Indicates a **REMOVAL** or **DISASSEMBLY** step.



Indicates an **INSTALLATION** or **ASSEMBLY** step.



INSPECTION is required.



CLEAN the part or assembly.



PERFORM a mechanical or time **MEASUREMENT**.



LUBRICATE the part or assembly.



Indicates that a **WRENCH** or **TOOL SIZE** will be given.



TIGHTEN to a specific torque.



PERFORM an electrical **MEASUREMENT**.



Refer to another location in this manual or another publication for additional information.




The component weighs 23 kg [50 lb] or more. To avoid personal injury, use a hoist or get assistance to lift the component.

Illustrations

Use the illustrations in this manual as a guide to perform the action or the repair described. Many illustrations are generic and will **not** look exactly like the engine or the parts used in your application. In order to provide clarity to illustrations, some illustrations show parts removed that are not related to the specific parts given in the text.

Most of the illustrations contain symbols to indicate an action required or to indicate an **acceptable (OK)** or **unacceptable (not OK)** condition.



Section E - Engine and Component Identification

Section Contents

	Page
Engine Identification	E-2
Engine Diagram	E-9
General Specifications	E-5
Injection Pump Dataplate	E-3


Definition of Terms
Page i-12

Section i - Introduction
C Series

Definition of Terms

AFC	Air Fuel Control	in-lb	Inch Pound
API	American Petroleum Institute	kg	Kilograms
ASA	Air Signal Attenuator	km	Kilometers
ASTM	American Society of Testing and Materials	km/l	Kilometers per Liter
C	Celsius	kPa	Kilopascal
CARB	California Air Resources Board	l	Liter
C.I.D.	Cubic Inch Displacement	m	Meter
Cm	Centimeter	mm	Millimeter
CPL	Control Parts List	MPa	Megapascal
cSt	Centistokes	MPH	Miles Per Hour
DCA	Diesel Coolant Additive	MPQ	Miles Per Quart
ECM	Electronic Control Module	N•m	Newton-meter
E.C.S.	Emission Control System	OEM	Original Equipment Manufacturer
EPA	Environmental Protection Agency	ppm	Parts Per Million
EPS	Engine Position Sensor	psi	Pounds Per Square Inch
F	Fahrenheit	PTO	Power Takeoff
ft-lb	Foot Pound	RPM	Revolutions Per Minute
GVW	Gross Vehicle Weight	S.A.E.	Society of Automotive Engineers
Hg	Mercury	STC	Step Timing Control
HP	Horsepower	VS	Variable Speed
H ₂ O	Water	VSS	Vehicle Speed Sensor



Engine Identification



Engine Dataplate

The engine dataplates show specific information about the engine. The engine serial number (1) and Control Parts List (CPL) (2) provide information for ordering parts and service needs.

NOTE: The engine dataplate **must not** be changed unless approved by Cummins Engine Company, Inc.

 Cummins Engine Company, Inc. Columbus, Indiana 47202-3005 Made in U.S.A.	Engine Cert. I.D. Certificat d'identité	C.I.D./ L. Pouce Cube/L	Family Famille	CPL	Model Modèle	FEL	EPA	CARB
	3925422				Catalyst No. Catalyseur No.	NOX		
<p>  WARNING Injury may result and warranty is voided if fuel rate rpm or altitudes exceed published maximum values for this model and application. AVERTISSEMENT: Danger de blessures et d'annulation de la garantie, si débit combustible, tr/mn ou altitude, dépassent les valeurs maximum annoncées pour ce modèle et son utilisation. </p>	Timing—T.D.C. Calage—P.M.H.				Engine No. Moteur No.	PM		
	Valve lash cold Jeux Soup.à Froid	Int. Adm.	Exh. Ech	Ref. No.				
	Firing Order Ordre d'Allumage			Fuel rate at adv. HP Débit combust. a puiss. indiquée	mm3 stroke			
Date of Mfg. Date of Fabrication	Idle Speed (rpm) Vitesse Ralenti	E.C.S.	Advertised HP Puiss. Indiquée (ch)	at a	rpm			

ap9plgb


Section E - Engine and Component Identification

Cummins Engine Nomenclature

The model name for engines in automotive applications provides the data shown in the example:

Example


C 8.3-275




The following example shows a model name of an engine for non-automotive applications:


Example

6 C T A 8.3




Engine Identification
Page E-3





Injection Pump Dataplate

The injection pump dataplate is located on the side of the injection pump. It provides information for fuel injection pump calibration.



The Cummins part number for the fuel injection pump and governor combination is located on the governor dataplate.

General Specifications

GENERAL ENGINE DATA	6C8.3	6CT8.3	6CTA8.3	C8.3
Bore - mm [in.]	-----	-----	114 [4.49]	-----
Stroke - mm [in.]	-----	-----	135 [5.32]	-----
Displacement - liter [in. ³]	-----	-----	8.27 [504.5]	-----
Engine Weight (Dry) With Standard Accessories	-----	603-612 Kg [1330-1350 lb]	-----	-----
Wet Weight	-----	635-658 Kg [1400-1450 lb]	-----	-----
Firing Order	-----	1-5-3-6-2-4	-----	-----
Valve Clearances	-----	-----	-----	-----
- Intake - mm [in.]	-----	0.30 [0.012]	-----	-----
- Exhaust - mm [in.]	-----	0.61 [0.024]	-----	-----
Compression Ratio	16.4:1	17.3:1	16.5:1	17.3:1*/18:1**
Rotation, viewed from the front of the engine	-----	-----	-----	-----
Aspiration	-----	-----	-----	-----
- Naturally Aspirated	X	-----	-----	-----
- Turbocharged	-----	X	-----	-----
- Aftercooled	-----	-----	X	-----
- Charge Air Cooled (CAC)	-----	-----	-----	X
* High Torque	-----	-----	-----	-----
* Low Torque	-----	-----	-----	-----

LUBRICATION SYSTEM	6C8.3	6CT8.3	6CTA8.3	C8.3
Lubricating Oil Pressure at Idle - (Minimum Allowable) kPa [PSI]	-----	69 [10]	-----	-----
Lubricating Oil Pressure at Rated - (Minimum Allowable) kPa [PSI]	-----	207 [30]	-----	-----
Regulating Valve Opening Pressure kPa [PSI]	-----	518 [75]	-----	-----
Differential Pressure to Open the Filter Bypass Valve - kPa [PSI]	-----	138 [20]	-----	-----
Lubricating Oil Capacity of Pan (High- Low) - Liter [U.S. Qts.]	-----	18.9 [20] 15.1 [16]	-----	-----
COOLING SYSTEM				
Coolant Capacity (Engine Only) - liter [U.S. Qts.]	9.9 [10.5]	9.9 [10.5]	10.9 [11.5]	9.9 [10.5]
Standard Modulating Thermostat - Range - °C [°F]	Start 81 [178]	-----	Fully Open 95 [203]	-----
Pressure Cap - kPa [PSI] Minimum	-----	50 [7]	-----	-----
Maximum Allowable Top Tank Temperature °C [°F]	-----	100°C [212°F]	-----	-----
Minimum Recommended Top Tank Temperature °C [°F]	-----	70°C [158°F]	-----	-----

INTAKE AIR, EXHAUST AND FUEL SYSTEM	6C8.3	6CT8.3	6CTA8.3	C8.3
Maximum Allowable Air Intake Restriction at Rated Speed and Load with Dirty Air Filter Element-mm H ₂ O (in. H ₂ O)	508 [20]	635 [25]	635 [25]	635 [25]
Maximum Allowable Exhaust Restriction at Rated Speed and Load - mm Hg (in. Hg)	-----	76 [3] 152 [6]*	-----	-----
Maximum Fuel Filter Pressure Drop Across Filters kPa [psi]	-----	34 [5]	-----	-----
Maximum Allowable Return Line Restriction - mm Hg [in Hg]	-----	518 [20.4]	-----	-----
Maximum Inlet Restriction to Fuel Transfer Pump mm Hg [in Hg]	-----	100 [4]	-----	-----

* with catalyst

ELECTRICAL SYSTEM

Minimum Recommended Battery Capacity

Battery Size	Ambient Temperatures			
	-18°C (0°F)		0°C (32°F)	
	Cold Cranking Amperes	Reserve Capacity *	Cold Cranking Amperes	Reserve Capacity *
12 Volt	1800	640	1280	480
24 Volt**	900	320	640	240

* The number of plates within a given battery size determines reserve capacity. Reserve capacity determines the length of time sustained cranking can occur.

** Per Battery (two 12 volt batteries in series) CCA ratings are based on -18°C [0°F].

Batteries (Specific Gravity)


Specific Gravity at 27°C [80°F]	State of Charge
1.260 - 1.280	100%
1.230 - 1.250	75%
1.200 - 1.220	50%
1.170 - 1.190	25%
1.110 - 1.130	Discharged

Section E - Engine and Component Identification C Series


Engine Diagrams Page E-9

Engine Diagrams

The illustrations which follow show the locations of the major external engine components, filters, and other service and maintenance points. Some external components will be at different locations for different engine models.




FUEL PUMP SIDE VIEW




ew900gr

REAR VIEW



ew900gp

EXHAUST SIDE VIEW



FRONT VIEW

ew900gs

Section 1 - Operating Instructions
C Series

Page 1-1

Section 1 - Operating Instructions


Section Contents

	Page
Cold Weather Starting Aids	1-6
Cold Weather Starting With Starting Fluid	1-7
Using Starting Fluid Without Metering Equipment	1-7
With Mechanical Or Electrical Metering Equipment	1-7
Engine Operating Range	1-10
Engine Shut-down Procedure	1-10
General Operating Instructions	1-2
Operating the Engine	1-9
Starting Procedure	1-2
Shutters	1-5
Starting Procedure Matrix	1-3
Winterfronts	1-5
Starting Procedure After Extended Shutdown or Oil Change	1-8

General Operating Instructions

Proper care of the engine will result in longer life, better performance, and more economical operation.

- Follow the daily maintenance checks listed in Section 2.
- Check the oil pressure indicator(s), temperature indicator(s), warning light(s), and other gauges daily to make sure they are operational.

 **Warning:** DO NOT OPERATE A DIESEL ENGINE WHERE THERE ARE OR CAN BE COMBUSTIBLE VAPORS. These vapors can be drawn through the air intake system and cause engine acceleration and over-speeding, which can result in a fire, an explosion and extensive property damage. Numerous safety devices are available, such as air intake shutoff devices, to minimize the risk of over-speeding where an engine, due to its application, might operate in a combustible environment, such as due to a fuel spill or gas leak. Remember, Cummins has no way of knowing the use you have for your engine. THE EQUIPMENT OWNER AND OPERATOR ARE RESPONSIBLE FOR SAFE OPERATION IN A HOSTILE ENVIRONMENT. CONSULT YOUR CUMMINS AUTHORIZED REPAIR LOCATION FOR FURTHER INFORMATION.

Starting Procedure

Automotive - (P-Pumps with RQV-K Governor) above 16°C [60°F]

Foot off throttle. The inline pump delivers sufficient fuel to start engine with throttle at idle.

Automotive - (P-Pumps with RQV-K Governor) below 16°C [60°F]

Fully depress the throttle **AFTER** engaging the starter. The inline pump requires open throttle to position and hold the rack in the maximum fuel position.

Industrial/Marine - (Bosch A, MW and Nippondenso EP-9 with RSV Governor) above 0°C [32°F]


Foot off throttle. The EP-9 with RSV governor and A, MW with RSV governor pump has a "Start Spring" which automatically moves the rack to the start fuel position.

Starting Procedure Matrix

	Idle Throttle	Full Throttle
Automotive		
All pumps - above 16°C [60°F].....	X	
All pumps - below 16°C [60°F].....		X
Industrial/Marine		
All pumps - above 0°C [32°F].....	X	

- Disengage the driven unit, or if equipped, put the transmission in neutral.
- Position the fuel shut-off, electrical switch or mechanism control to the RUN position.
- With Bosch in-line pumps, fully depress the throttle **AFTER** engaging the starter.

NOTE: Industrial engines are equipped with Robert Bosch RSV governors which automatically position the internal pump controls to the **START** position for maximum fuel delivery when the throttle is set at idle.

 **Caution:** To prevent damage to the starter and fuel shutoff solenoid, do not engage the starting motor more than 30 seconds. Wait 2 minutes between each attempt to start (electrical starting motors only).

- If the engine does not start after three attempts, check the fuel supply system. Absence of blue or white exhaust smoke during cranking indicates no fuel is being delivered.
- Move the throttle position to idle as soon as the engine starts.

- Engine oil pressure **must** be indicated on the gauge within 15 seconds after starting.
- When starting a cold engine, increase the engine speed (RPM) slowly to be sure adequate lubrication is available to the bearings and to allow the oil pressure to stabilize.

⚠ Caution: Do not idle the engine for excessively long periods. Long periods of idling (more than 10 minutes) can damage an engine because combustion chamber temperatures drop so low the fuel will not burn completely. This will cause carbon to clog the injector spray holes and piston rings, and can cause the valves to stick. If the engine coolant temperature becomes too low (60°C [140°F]), raw fuel will wash the lubricating oil off the cylinder walls and dilute the crankcase oil; therefore, all moving parts of the engine will not receive the correct amount of lubrication.

- Idle the engine 3 to 5 minutes **before** operating with a load.

⚠ Caution: When using jumper cables to start the engine, make sure to connect the jumper cables in parallel: positive (+) to positive (+) and negative (-) to negative (-). When using an external electrical source to start the engine, turn the disconnect switch to the "OFF" position. Remove the key before attaching the jumper cables to prevent unintentional starter engagement.

Section 1 - Operating Instructions C Series



Winterfronts

Winterfronts can be used on a vehicle equipped with charge air cooling (CAC), but **must** be designed to partially cover the frontal area of the cooling system. A minimum of 120 square inches (11 in x 11 in) of frontal area **must** be left open to air flow for the CAC to function correctly.

Shutters


Installations of CAC engines with shutters also requires an intake manifold air temperature switch to open the shutters at 65.5°C [150°F] to prevent excessive intake manifold temperatures. This prevents engine damage due to high intake manifold temperatures as a result of blocked air flow across the CAC.

Starting Procedure Page 1-5



Cold Weather Starting Aids

Use the following chart as a reference for required cold weather starting aids:



Cold Weather Starting With Starting Fluid

With Mechanical Or Electrical Metering Equipment

NOTE: Industrial engines are equipped with Robert Bosch RSV governors which automatically position the pump controls to the **START** position when the throttle is set at idle. Automotive engines are equipped with Bosch RQV and RQV-K governors. The accelerator pedal must be depressed all the way to the **START** position **after** engaging the starter.

- Disengage the driven unit or put the transmission in neutral.
- Position the fuel shutoff, electrical switch or mechanical control, to the **RUN** position.
- On industrial equipment, set the throttle at idle. For automotive engines, **after engaging the starter**, depress the accelerator pedal all the way to the **START** position and hold the pedal.
- While cranking the engine, inject metered amounts of starting fluid.
- Engine lubricating oil pressure **must** be indicated on the gauge within 30 seconds after starting.

Using Starting Fluid Without Metering Equipment




- ⚠ **Warning:** Never use starting fluid near an open flame, or with a preheater or flame thrower equipment. This combination can cause an explosion.
- ⚠ **Warning:** Do not breathe starting fluid fumes. Starting fluid fumes can be harmful to your health.
- ⚠ **Caution:** Do not use excessive amounts of starting fluid when starting an engine. The use of too much starting fluid will cause engine damage.
 - Spray starting fluid into the air cleaner intake while another person cranks the engine.
- ⚠ **Warning:** Do not use volatile cold starting aids in underground mine or tunnel operations due to the potential of an explosion. Check with the local U.S. Bureau of Mines Inspector for Instructions.

Starting Procedure After Extended Shutdown or Oil Change

Complete the following steps after each lubricating oil change, or after the engine has been shut off for more than 7 days to make sure the engine receives the correct oil flow through the lubricating oil system:

- Disconnect the electrical wire from the fuel injection pump solenoid valve.
- Rotate the crankshaft, using the starting motor, until oil pressure appears on the gauge, or the warning light goes out.
- Connect the electrical wire to the fuel injection pump solenoid valve.
- Start the engine; refer to Normal Starting Procedures in this section.
- Refer to Fuel System - Bleeding, Section 5, for instructions to vent the fuel system.

Engine Operating Range

-  **Caution:** Cummins engines are designed to operate successfully at full throttle under transient conditions down to peak torque engine speed (RPM). This is consistent with recommended driving practices for good fuel economy. Excessive full throttle operation below peak torque RPM (peak torque RPM varies from 1,100 RPM to 1,500 RPM, depending upon rated engine speed) will shorten engine life to overhaul, can cause serious engine damage, and is considered engine abuse.
-  **Caution:** Operation of the engine below peak torque RPM can occur during gear shifting due to the difference of ratios between transmission gears, but engine operation must not be sustained more than one minute at full throttle below peak torque RPM.
-  **Caution:** Operating the engine beyond high idle speed can cause severe engine damage. When descending a steep grade, use a combination of transmission gears and engine or service brakes to control the vehicle and engine speed.

Engine Shut-down Procedure

- Allow the engine to idle 3 to 5 minutes after a full load operation before shutting the engine off. This allows the engine to cool gradually and uniformly.
- Turn the ignition key switch to the **OFF** position.

Operating the Engine

- Do **not** operate the engine at full throttle below peak torque engine speed (RPM) for extended periods (more than a minute) of time.
- Allow the engine to idle 3 to 5 minutes before shutting the engine off after a full load operation.
- Monitor the lubricating oil pressure and coolant temperature gauges frequently. Refer to **Engine Specifications** (Section V) for recommended operating pressures and temperatures. Shut the engine off if any pressure or temperature does not meet the specifications.



Caution: Continuous operation with low coolant temperature (below 60°C [140°F]) or high coolant temperature (above 100°C [212°F]) can damage the engine.

- If an overheating condition starts to occur, reduce engine speed or shift to a lower gear, or both, until the temperature returns to normal operating range. If engine temperature does **not** return to normal, refer to **Troubleshooting** (Section T) or contact a Cummins Authorized Repair Location.
- Most failures give an early warning. Look and listen for changes in performance, sound, or engine appearance that can indicate service or engine repair is needed. Some changes to look for are:
 - Engine misfires
 - Vibration
 - Unusual engine noises
 - Fuel, oil or coolant leaks
 - Sudden changes in engine operating temperature or pressure
 - Excessive smoke
 - Loss of power
 - An increase in oil consumption
 - An increase in fuel consumption

Section 2 - Maintenance Guidelines

Section Contents

	Page
General Information	2-2
Maintenance Record Form	2-8
Maintenance Schedule	2-4
Tool Requirements	2-3

General Information

Cummins Engine Company, Inc. recommends that the engine be maintained according to the Maintenance Schedule on page 2-4.

If the engine is operating in ambient temperatures consistently below -18°C [0°F] or above 38°C [100°F], perform maintenance at shorter intervals. Shorter maintenance intervals are also required if the engine is operated in a dusty environment or if frequent stops are made. See your Cummins Authorized Repair Location for recommended intervals.

Use the chart provided on page 2-8 as a convenient way to keep a record of maintenance performed.

*If the engine is equipped with a component or an accessory **not** manufactured by Cummins Engine Company, Inc., refer to the component manufacturer's maintenance recommendations. A listing of suppliers' addresses and telephone numbers is provided in Component Manufacturers, Section C.

Section 2 - Maintenance Guidelines C Series

Tool Requirements Page 2-3

Tool Requirements

In the text, a symbol followed by the wrench size or tool description is used to identify the tooling required to perform each step. A list of wrench sizes and descriptions indicate more than one tool is needed.

Sockets	Wrenches	Other Tools
	19 mm	
19mm	17mm	Filter Wrenches (75-80mm, 90-95mm and 118-131mm)
17mm	15mm	Ratchet (1/2 and 3/8 inch drive)
15mm	14mm	Torque Wrench
	13mm	Flat Blade Screwdriver
	10mm	5/16 Allen Wrench
		Feeler Gauges (0.30 mm and 0.61 mm)
		Engine Barring Gear Part No. 3377371
		DCA4 Test Kit, Fleetguard Part No. CC-2626
		3823276 Injector Puller

C Series Engine Maintenance Schedule

Daily or Refueling	Every 10,000 Km (6,000 Mi) Or 250 Hours, 3 Months	Every 19,000 Km (12,000 Mi) Or 500 Hours, 6 Months	Every 38,000 Km (24,000 Mi) Or 1000 Hours, 12 Months	Every 77,000 Km (48,000 Mi) Or 2000 Hours, 2 Years
Check	Change/Replace			
• Lubricating Oil Level	• Lubricating Oil ^①	• Lubricating Oil	• Lubricating Oil	• Lubricating Oil
• Coolant Level	• Lubricating Filter	• Lubricating Filter	• Lubricating Filter	• Lubricating Filter
• Drive Belt	• Coolant Filter	• Coolant Filter ^⑤	• Coolant Filter	• Coolant Filter
• Fuel Water Trap		• Fuel Filter ^⑤	• Fuel Filter	• Fuel Filter
				• Antifreeze ^③
				• Fuel Strainer
	Adjust			
			• Valve Lash ^② Clearance	• Valve Lash Clearance
	Check/Inspect			
	• Air Cleaner	• Air Cleaner	• Air Cleaner	• Air Cleaner
	• Intake System	• Intake System	• Intake System	• Intake System
	• Charge Air Cooler	• Antifreeze	• Antifreeze	• Air Compressor
		• Charge Air Cooler	• Fan Hub	• Fan Hub
			• Belt Tensioner Bearing	• Belt Tensioner Bearing
			• Belt Tension	• Belt Tension
			• Charge Air Cooler	• Vibration Damper
				• Charge Air Cooler ^④

^① Refer to the Lubricating Oil Change Interval chart given in Section 4 to find the correct lubricating oil change interval for the engine application.

^② Initial valve lash clearance adjustment, subsequent adjustments to be performed at every 4th engine oil change for automotive engines or 77,000 Km (48,000 Mi), 2000 Hrs or 2 years interval, whichever occurs first.

^③ Must use a heavy duty antifreeze that meets the chemical composition of GM6038-M. The change interval is 2 years or 385,000 Km [240,000 Mi] for industrial engines.

^④ Service interval is 2 years, or 320,000 Km [200,000 Mi], whichever occurs first.

^⑤ Service interval is every other engine oil change or 19,000 Km [12,000 mi], 500 hours or 6 months.

Section 2 - Maintenance Guidelines C Series

C Series Engine Maintenance Schedule Page 2-5

Page References for Maintenance Instructions

For your convenience, listed below are the page numbers which contain specific instructions for performing the maintenance checks listed in the maintenance schedule:

Daily or Refueling

• Belts - inspect	3-5
• Engine oil level - check	3-3
• Engine coolant level - check	3-4
• Fan - inspect	3-6
• Fuel-water separator - drain	3-3

Every 10,000 Kilometers [6,000 Miles], 250 Hours or 3 Months

• Lubricating oil - change	4-3
• Lubricating oil filters - change	4-5
• Air intake system - check	4-11
• Air cleaner restriction - check	4-11
• Charge Air Cooler	4-11

Every 19,000 Kilometers [12,000 Miles], 500 Hours or 6 Months

- Lubricating oil - change 4-3
- Lubricating oil filter - change 4-5
- Fuel filter - change 5-3
- Intake air system - check 4-11
- Coolant and Antifreeze - check 5-8
- Charge Air Cooler 4-11

Every 38,000 Kilometers [24,000 Miles], 1000 Hours or 12 Months

- Lubricating oil - change 4-3
- Lubricating oil filter - change 4-5
- Fuel filter - change 5-3
- Valve lash clearance - adjust 6-3
- Fan hub - check 6-11
- Belt tensioner bearing - check 6-11
- Belt tension - check 6-10
- Coolant and antifreeze - check 5-8

Every 77,000 Kilometers [48,000 Miles], 2,000 Hours or 2 Years

- Lubricating oil - change 4-3
- Lubricating oil filters - change 4-5
- Fuel filter - change 5-3
- Valve lash clearance - adjust 6-3
- Fan hub - check 6-11
- Belt tensioner bearing - check 6-11
- Belt tension - check 6-10
- Vibration damper - inspect 7-8
- Coolant and antifreeze - change 7-3
- Charge Air Cooler - Leak Check (320,000 Km/200,000 Mi) A-64

Maintenance Record	
Engine Serial No. _____	Engine Model _____
Owner's Name _____	Equipment Name/Number _____

Date	Km (Miles), Hours or Time Interval	Actual Km (Miles) or Hours	Maintenance Check Performed	Check Performed By	Comments

Section 3 - Daily Maintenance Procedures

Section Contents

	Page
Coolant Level	3-4
Checking	3-4
Cooling Fan	3-6
Inspection	3-6
Drive Belt	3-5
Inspection	3-5
Fuel-Water Separator	3-3
Draining	3-3
General Information	3-2
Lubricating Oil Level	3-3
Checking	3-3

General Information

Preventative maintenance begins with day-to-day awareness of the condition of the engine and its systems. Before starting the engine, check the lubricating oil and coolant levels, look for:

- Leaks
- Loose or damaged parts
- Worn or damaged belts
- Any change in engine appearance

Section 3 - Daily Maintenance Procedures C Series

Fuel-Water Separator Page 3-3

Fuel-Water Separator


Draining

Drain the water and sediment from the fuel-water separator daily.

Shut off the engine. Open the drain valve. Turn the valve **counterclockwise** approximately 1 1/2- to 2 turns until draining occurs. Drain the fuel-water separator of water and sediment until clear fuel is visible.

Caution: Do not overtighten the valve. Overtightening can damage the threads.

Turn the valve **clockwise** to close the drain valve.



Lubricating Oil Level


Checking


Never operate the engine with the lubricating oil level below the "L" (Low) mark or above the "H" (High) mark. Wait at least 5 minutes after shutting off the engine to check the lubricating oil. This allows time for the lubricating oil to drain to the oil pan.

NOTE: The engine **must** be level when checking the lubricating oil level to make sure the measurement is correct.

Lubricating Oil Capacity: Low Mark To High Mark

3.8 Litres [4 U.S. Quarts]





Coolant Level

Checking


Warning: Do not remove the radiator cap from a hot engine. Wait until the temperature is below 50°C [122°F] before removing the pressure cap. Failure to do so can result in personal injury from heated coolant spray or steam. Remove the filler cap slowly to relieve coolant system pressure.

NOTE: Never use a sealing additive to stop leaks in the coolant system. This can result in coolant system plugging and inadequate coolant flow causing the engine to overheat.

The coolant level **must** be checked daily.

Caution: Do not add cold coolant to a hot engine. Engine castings can be damaged. Allow the engine to cool to below 50°C [122°F] before adding coolant.

NOTE: If additional coolant is added to the cooling system a 50% mixture of water and antifreeze **must** be premixed before added to the system. Since the ability of antifreeze to remove heat from the engine is not as good as water, pouring antifreeze into the engine first could contribute to an over heated condition before the liquids are completely mixed.




Section 3 - Daily Maintenance Procedures C Series

Fill the cooling system with coolant to the bottom of the fill neck in the radiator fill or expansion tank.

NOTE: Some radiators have two fill necks, both of which **must** be filled when the cooling system is drained.


Drive Belt Page 3-5




Drive Belt

Inspection

Visually inspect the belt. Check the belt for intersecting cracks. Transverse (across the belt width) cracks are acceptable. Longitudinal (direction of belt length) cracks that intersect with transverse cracks are **not** acceptable. Replace the belt if it is frayed or has pieces of material missing. Refer to **Adjustment and Replacement** (Section A).





Cooling Fan

Inspection



Warning: Personal injury can result from a fan blade failure. Never pull or pry on the fan. This can damage the fan blade(s) and cause fan failure.

NOTE: Rotate the crankshaft by using the engine barring gear, Part No. 3377371.



A visual inspection of the cooling fan is required daily. Check for cracks, loose rivets, and bent or loose blades. Check the fan to make sure it is securely mounted. Tighten the capscrews if necessary. Replace any fan that is damaged.

Section 4 - Maintenance Procedures at 10,000 Kilometers [6,000 Miles], 250 Hours or 3 Months

Section Contents

	Page
Air Cleaner	4-11
Restriction	4-11
Air Intake System	4-11
Inspection	4-11
Charge Air Cooler	4-11
General Information	4-2
Lubricating Oil and Filter	4-5
Changing	4-5
Lubricating Oil and Filter Change Interval	4-3

General Information

All checks or inspections listed under daily or previous maintenance intervals **must** also be performed at this time in addition to those listed under this maintenance interval.

Maintenance Procedures at 10,000 Km [6,000 Mi] C Series

Lubricating Oil and Filter Change Interval Page 4-3

Lubricating Oil and Filter Change Interval

Refer to the following charts to determine the maximum recommended lubricating oil and filter change interval in kilometers [miles], hours or months; whichever occurs first:

Is your vehicle an On-Highway application?	YES	Is your vehicle one of those below? - Regional Haul Truck - Coach Bus - Vehicle accum 8000 miles/mth. or more.	YES	Change Interval KM 16,000 MILES 10,000 HOURS 250 MOS 3																																													
	NO	NO	<p>Use the following oil drain intervals for your application (1):</p> <table border="1"> <thead> <tr> <th>VEH/EQUIP</th> <th>KM</th> <th>MILES</th> <th>HRS</th> <th>MOS</th> </tr> </thead> <tbody> <tr><td>Refuse Trk</td><td>10,000</td><td>6,000</td><td>250</td><td>3</td></tr> <tr><td>Mixer/Dumper</td><td>10,000</td><td>6,000</td><td>250</td><td>3</td></tr> <tr><td>Del. Truck</td><td>10,000</td><td>6,000</td><td>250</td><td>6</td></tr> <tr><td>Shuttle or Transit Bus</td><td>10,000</td><td>6,000</td><td>250</td><td>3</td></tr> <tr><td>School Bus</td><td>10,000</td><td>6,000</td><td>250</td><td>6</td></tr> <tr><td>Fire Truck</td><td>10,000</td><td>6,000</td><td>250</td><td>3</td></tr> <tr><td>Recreational Vehicle</td><td>10,000</td><td>6,000</td><td>250</td><td>6</td></tr> </tbody> </table>		VEH/EQUIP	KM	MILES	HRS	MOS	Refuse Trk	10,000	6,000	250	3	Mixer/Dumper	10,000	6,000	250	3	Del. Truck	10,000	6,000	250	6	Shuttle or Transit Bus	10,000	6,000	250	3	School Bus	10,000	6,000	250	6	Fire Truck	10,000	6,000	250	3	Recreational Vehicle	10,000	6,000	250	6					
VEH/EQUIP	KM	MILES	HRS	MOS																																													
Refuse Trk	10,000	6,000	250	3																																													
Mixer/Dumper	10,000	6,000	250	3																																													
Del. Truck	10,000	6,000	250	6																																													
Shuttle or Transit Bus	10,000	6,000	250	3																																													
School Bus	10,000	6,000	250	6																																													
Fire Truck	10,000	6,000	250	3																																													
Recreational Vehicle	10,000	6,000	250	6																																													
Is your vehicle used in a Construction, Mining or Logging Application?	YES	Use the following oil drain intervals for your application (1):	<table border="1"> <thead> <tr> <th>VEHICLE/EQUIP</th> <th>KM</th> <th>MILES</th> <th>HRS</th> <th>MOS</th> </tr> </thead> <tbody> <tr><td>Truck Crane</td><td>10,000</td><td>6,000</td><td>250</td><td>3</td></tr> <tr><td>Yard Spotter</td><td>10,000</td><td>6,000</td><td>250</td><td>3</td></tr> <tr><td>Paver</td><td>N/A</td><td>N/A</td><td>250</td><td>6</td></tr> <tr><td>Cranes</td><td>N/A</td><td>N/A</td><td>250</td><td>6</td></tr> <tr><td>Backhoe</td><td>N/A</td><td>N/A</td><td>250</td><td>6</td></tr> <tr><td>Dozer</td><td>N/A</td><td>N/A</td><td>250</td><td>6</td></tr> <tr><td>Scraper</td><td>N/A</td><td>N/A</td><td>250</td><td>6</td></tr> <tr><td>Skidder</td><td>N/A</td><td>N/A</td><td>250</td><td>6</td></tr> </tbody> </table>		VEHICLE/EQUIP	KM	MILES	HRS	MOS	Truck Crane	10,000	6,000	250	3	Yard Spotter	10,000	6,000	250	3	Paver	N/A	N/A	250	6	Cranes	N/A	N/A	250	6	Backhoe	N/A	N/A	250	6	Dozer	N/A	N/A	250	6	Scraper	N/A	N/A	250	6	Skidder	N/A	N/A	250	6
VEHICLE/EQUIP	KM	MILES	HRS	MOS																																													
Truck Crane	10,000	6,000	250	3																																													
Yard Spotter	10,000	6,000	250	3																																													
Paver	N/A	N/A	250	6																																													
Cranes	N/A	N/A	250	6																																													
Backhoe	N/A	N/A	250	6																																													
Dozer	N/A	N/A	250	6																																													
Scraper	N/A	N/A	250	6																																													
Skidder	N/A	N/A	250	6																																													
Is your vehicle used in an Agricultural or Stationary Power Application?	YES	Use the following oil drain intervals for your application (1):	<table border="1"> <thead> <tr> <th>VEHICLE/EQUIP</th> <th>HOURS</th> <th>MONTHS</th> </tr> </thead> <tbody> <tr><td>Farm Tractors</td><td>250</td><td>6</td></tr> <tr><td>Combines</td><td>250</td><td>6</td></tr> <tr><td>Irrigation Equip.</td><td>250</td><td>6</td></tr> <tr><td>Generator Set</td><td>250</td><td>6</td></tr> <tr><td>Air Compressor</td><td>250</td><td>6</td></tr> <tr><td>Fire Pump</td><td>250</td><td>6</td></tr> <tr><td>Pleasure Boat</td><td>250</td><td>6</td></tr> <tr><td>Work Boat</td><td>250</td><td>3</td></tr> </tbody> </table>		VEHICLE/EQUIP	HOURS	MONTHS	Farm Tractors	250	6	Combines	250	6	Irrigation Equip.	250	6	Generator Set	250	6	Air Compressor	250	6	Fire Pump	250	6	Pleasure Boat	250	6	Work Boat	250	3																		
VEHICLE/EQUIP	HOURS	MONTHS																																															
Farm Tractors	250	6																																															
Combines	250	6																																															
Irrigation Equip.	250	6																																															
Generator Set	250	6																																															
Air Compressor	250	6																																															
Fire Pump	250	6																																															
Pleasure Boat	250	6																																															
Work Boat	250	3																																															
	NO	Change Interval KM 10,000 MILES 6,000 HOURS 250 MOS 3																																															

(1) Or whichever comes first. If your application accumulates high hours and low mileage, the change interval is determined by hours.

Example: Transit bus and refuse trucks may average 16 Km/h [10 MPH] when used in an all urban route. Oil drain intervals in those applications are 4800 Km [3,000 mi], or less.

Maintenance Procedures at 10,000 Km [6,000 Mi]
C Series

Lubricating Oil and Filter
Page 4-5

Lubricating Oil and Filter


Changing



Caution: Avoid prolonged and repeated skin contact with used engine lubricating oils. Such prolonged and repeated contact may cause skin disorders or other bodily injury.

- Avoid excessive contact - wash thoroughly after contact.
- Keep out of reach of children.


PROTECT THE ENVIRONMENT: Handling and disposal of used engine lubricating oil may be subject to federal, state and local law and regulation. Use authorized waste disposal facilities, including civic amenity sites and garages providing authorized facilities for receipt of used lubricating oil. If in doubt, contact your state and local environmental authorities or the Environmental Protection Agency for guidance as to proper handling and disposal of used engine lubricating oil.



NOTE: If the engine is in service, under no circumstances can the lubricating oil drain interval extend beyond the intervals given in the charts.

Change the lubricating oil and filters to remove the contaminants suspended in the lubricating oil.

NOTE: Drain the lubricating oil only when it is hot and the contaminants are in suspension.



17 mm



Caution: Hot lubricating oil can cause personal injury.

Operate the engine until the water temperature reaches 60°C [140°F]. Shut the engine off. Remove the lubricating oil drain plug.




NOTE: Use a container that can hold at least 25 liters [27 U.S. qts.] of lubricating oil.

Maintenance Procedures at 10,000 Km [6,000 Mi]
C Series

118 to 131 mm Filter Wrench

Clean the area around the lubricating oil filter head. Remove the filter. Clean the gasket surface of the filter head.

NOTE: The o-ring can stick on the filter head. Make sure it is removed.





Lubricating Oil and Filter
Page 4-7

Caution: Fill the filters with clean lubricating oil before installation.

Apply a light film of lubricating oil to the gasket sealing surface before installing the filters.


NOTE: The LF3000 lubricating oil filter has two gaskets. Lubricate both gaskets.





Caution: Mechanical over-tightening may distort the threads or damage the lubricating oil filter element seal.

Install the lubricating oil filter as specified by the filter manufacturer.



17 mm

Check and clean the lubricating oil drain plug threads and sealing surface.

Install the lubricating oil pan drain plug.

Torque Value: 80 N•m [60 ft-lb]

**Maintenance Procedures at 10,000 Km [6,000 Mi]
C Series**

NOTE: Use a high quality 15W-40 multi-viscosity lubricating oil, such as Cummins Premium Blue, or its equivalent in Cummins engines. Choose the correct lubricating oil for your operating climate as outlined in Section V.




**Lubricating Oil and Filter
Page 4-9**




Fill the engine with clean lubricating oil to the proper level.


System Capacity

23.8 Liter [25.2 U.S. Quart]





Operate the engine at low idle to inspect for leaks at the lubricating oil filter and the drain plug.



Stop the engine. Wait approximately 5 minutes to let the lubricating oil drain from the upper parts of the engine. Check the level again.

Add lubricating oil as necessary to bring the lubricating oil level to the "H" (High) mark on the dipstick.

Maintenance Procedures at 10,000 Km [6,000 Mi]
C Series


Air Intake System
Page 4-11

Air Intake System

Inspection

Inspect the intake piping for cracked hoses, loose clamps, or punctures which may damage the engine.


Tighten or replace parts as necessary to make sure the air intake system does not leak.




Charge Air Cooler

Visually inspect the CAC for cracks, holes or damage.

Inspect the tubes, fins and welds for tears, breaks or other damage.






If the engine experiences a turbocharger failure or any other occasion where oil or debris is put into the CAC, the CAC **must** be cleaned.



Remove the CAC from the vehicle. Refer to the vehicle manufacturer's instructions.



Caution: Do not use caustic cleaners to clean the CAC. Damage to the CAC will result.


Flush the CAC internally with solvent in the opposite direction of normal air flow. Shake the CAC and lightly tap on the end tanks with a rubber mallet to dislodge trapped debris. Continue flushing until all debris or oil is removed.

Maintenance Procedures at 10,000 Km [6,000 Mi] C Series

After the CAC has been thoroughly cleaned of all oil and debris with solvent, wash the CAC internally with hot soapy water to remove the remaining solvent. Rinse thoroughly with clean water.

Blow compressed air into the CAC in the opposite direction of normal air flow until the CAC is dry internally.

Refer to the vehicle manufacturer's instructions for installation.





Air Cleaner Page 4-13

Air Cleaner Restriction

Maximum intake air restriction is 635 mm [25.0 in.] of water for turbocharged engines. Naturally aspirated engines have a maximum restriction of 510 mm [20.0 in.] of water.

The engine must be operated at rated RPM and full load to check maximum intake air restriction. Replace the air cleaner element when the restriction reaches the maximum allowable limit or clean according to the manufacturer's recommendations.





NOTE: Follow the manufacturer's instructions when cleaning or replacing the air cleaner element.

Check the air cleaner service indicator, if equipped. Change the filter element when the red indicator flag (2) is at the raised position in the window (1).

After the air cleaner has been serviced, reset the button (3) in the end of the service indicator.

NOTE: Never operate the engine without an air cleaner. Intake air must be filtered to prevent dirt and debris from entering the engine and causing premature wear.

Section 5 - Maintenance Procedures at 19,000 Kilometers [12,000 Miles], 500 Hours or 6 Months

Section Contents

	Page
Antifreeze Concentration.....	5-8
Checking	5-8
Coolant Additive Concentration	5-8
Checking	5-8
Coolant Filter/DCA4 Corrosion Resistor Cartridge	5-9
Coolant Filter.....	5-10
Replacement	5-10
Fuel Filter.....	5-3
Replacement	5-3
Fuel System	5-5
Bleeding.....	5-5
General Information.....	5-2
High Pressure Lines	5-7
Venting	5-7
Low Pressure Lines and Fuel Filter(s)	5-6
Venting	5-6

General Information

All checks or inspections listed under daily or previous maintenance intervals **must** also be performed at this time in addition to those listed under this maintenance interval.

Maintenance Procedures at 19,000 Km [12,000 Mi.] C Series


Fuel Filter

Replacement

75-80 mm and 90-95 mm

Clean the area around the fuel filter head. Remove the filters. Clean the gasket surface of the fuel filter head.


Replace the o-ring.



Fill the new fuel filter(s) with clean fuel and lubricate the o-ring seal with clean 15W-40 engine lubricating oil.



Fuel Filter Page 5-3



Caution: To prevent fuel leaks, make sure the fuel filter is installed tightly but not overtightened. Mechanical tightening will damage the fuel filter.

Install the fuel filter as specified by the filter manufacturer.


Fuel System

Bleeding

Controlled venting is provided at the injection pump through the fuel drain manifold. Small amounts of air introduced by changing the fuel filters or fuel injection pump supply line will be vented automatically, if the fuel filter is changed in accordance with the instructions.

NOTE: Manual bleeding is required if:

- The fuel filter is not filled prior to installation.
- Fuel injection pump is replaced.
- High pressure fuel line connections are loosened or fuel lines replaced.
- Initial engine start up or start up after an extended period of no engine operation.
- Vehicle fuel tank has been run until empty.





Low Pressure Lines and Fuel Filter(s)

Venting

10 mm

Open the bleed screw.



10 mm

Operate the plunger on the fuel transfer pump until the fuel flowing from the fitting is free of air.

Tighten the bleed screw.

Torque Value: 9 N•m

[80 in-lb]




High Pressure Lines

Venting

17 mm (PES.A, PES.MW), 19 mm (PES.P)

Warning: The pressure of the fuel in the line is sufficient to penetrate the skin and cause serious bodily harm.


Loosen the fittings at the injectors, and crank the engine to allow entrapped air to bleed from the lines. Tighten the fittings.



Warning: It is necessary to put the engine in the "RUN" position. Because the engine could start, be sure to follow all the safety precautions. Use the normal engine starting procedure.

Start the engine and vent one line at a time until the engine runs smoothly.

NOTE: Do not engage the starter for more than 30 seconds each time when it is used to vent the system: wait 2 minutes between engagements.



Antifreeze Concentration

Checking

Check the antifreeze concentration. Use ethylene-glycol base antifreeze to protect the engine to -37°C [-34°F] throughout the year.


Antifreeze is essential in all climates. It broadens the operating temperature range by lowering the coolant freezing point and by raising the coolant boiling point.

Coolant Additive Concentration

Checking

Caution: Inadequate concentration of the coolant additive can result in major corrosive damage to cooling system components. Over concentration can cause formation of "gel" that can cause restriction, plugging of coolant passages, and overheating.

NOTE: If the engine coolant is changed, the coolant filters must also be changed.




Maintenance Procedures at 19,000 Km [12,000 Mi.] C Series

The cooling system must contain the proper coolant additive units to provide the best chemical protection. Refer to the **Engine Specifications** (Section V).

DCA4 Test Kit: Use only DCA4 Coolant Test Kit, Fleetguard® Part No. CC-2626 to check the coolant additive concentration in the cooling system.


Coolant Additive Concentration Page 5-9




Coolant Filter/DCA4 Corrosion Resistor Cartridge

The correct coolant filter to be used is determined by the total cooling system capacity and other operational factors.

Refer to the DCA4 Maintenance Guide in Engine Specifications (Section V) for the correct selection of the filter.






Coolant Filter

Replacement



Warning: Do not remove the radiator cap from a hot engine. Hot steam will cause serious personal injury. Wait until the coolant temperature is below 50°C [122°F] before removing the pressure cap. Remove the coolant system pressure cap and close the shutoff valve before removing the coolant filter. Failure to do so can result in personal injury from heated coolant spray.



Remove and discard the coolant filter. Clean the coolant filter gasket surface.



Maintenance Procedures at 19,000 Km [12,000 Mi.] C Series


Apply a light film of clean 15W-40 lubricating oil to the gasket sealing surface before installing the coolant filter.

Caution: Mechanical over-tightening may distort the threads or damage the coolant filter head.

Install the filter as specified by the filter manufacturer.




Coolant Filter Page 5-11



Open the engine coolant shutoff valve and install the coolant system pressure cap.

NOTE: Failure to open the engine coolant shutoff valve can result in severe engine damage.



Section 6 - Maintenance Procedures at 38,000 Kilometers [24,000 Miles], 1000 Hours or 1 Year

Section Contents

	Page
Drive Belt Tension	6-10
Checking	6-10
Drive Belt, Tensioner Bearing and Fan Hub	6-11
Inspection	6-11
General Information	6-2
Valve Clearance	6-3
Adjusting	6-3

Maintenance Procedures at 38,000 Kilometers [24,000 Mi] C Series


Valve Clearance Page 6-3

Valve Clearance

Adjusting


Screwdriver


Remove the air crossover tube if the engine is so equipped.



10 and 15 mm


Disconnect the support clamps, hose clamp and waste-gate sensing line. Remove the crankcase vent tube and any other parts that would prevent removal of the valve cover.





15 mm

Remove the valve cover.




1/2 Inch Drive, 3377381 Barring Gear

Locate Top Dead Center (TDC) for Cylinder Number 1 by rotating the crankshaft slowly while pressing on the engine timing pin.


Maintenance Procedures at 38,000 Kilometers [24,000 Mi]
C Series


When the engine timing pin engages the hole in the camshaft gear, Cylinder Number 1 is at TDC on the compression stroke.

Valve Clearance
Page 6-5



Caution: Be sure to disengage the engine timing pin after locating TDC to prevent damage to the engine timing pin.






Feeler Gauge

Intake Clearance: 0.30 mm [0.012 inch]

Exhaust Clearance: 0.61 mm [0.024 inch]

Check/set valves with engine cold - below 60°C [140°F].

NOTE: The clearance is correct when some resistance is "felt" when the feeler gauge is slipped between the valve stem and the rocker lever.



14 mm, Flatblade Screwdriver

Locate Top Dead Center (TDC) for Cylinder Number 1.

Check/adjust the valves indicated for STEP A (I = Intake; E = Exhaust).

After tightening the rocker lever lock nut, check the valve clearance to make sure the valve clearance has not changed.




Torque Value: 24 N•m [18 ft-lb]

Maintenance Procedures at 38,000 Kilometers [24,000 Mi] C Series

Mark the vibration damper and rotate the crankshaft 360 degrees.

Caution: Be sure the engine timing pin is disengaged to prevent damage to the engine timing pin.




Valve Clearance Page 6-7


14 mm, Flatblade Screwdriver

Set the valves indicated for STEP B.


After tightening the rocker lever lock nut, check the valve clearance to make sure the valve clearance has not changed.

Torque Value: 24 N•m [18 ft-lb]





Install the rubber seal into the groove in the valve cover. Start the installation at the overlap area shown in the illustration. **Do not stretch the rubber seal.**



15 mm

Install new sealing o-rings on the cap screws.



Install the valve cover and wastegate sensing tube.



Torque Value: 24 N•m [18 ft-lb]

Maintenance Procedures at 38,000 Kilometers [24,000 Mi]
C Series


Valve Clearance
Page 6-9

10 and 15 mm

Install the crankcase vent tube and secure with the support clamps and hose clamp.


A = 24 N•m [18 ft-lb]


B = 43 N•m [32 ft-lb]



Screwdriver

Install the air crossover tube and any other parts previously removed to gain access to the valve cover.






Drive Belt Tension

Checking

Measure the belt deflection at the longest span of the belt.

Maximum Deflection: 9.5 to 12.7mm [3/8 to 1/2 inch]



NOTE: The Cummins belt tension gauge ST-1293 can be used.

Tension Limit: 360 to 490 N [80 to 100 lbf]

Maintenance Procedures at 38,000 Kilometers [24,000 Mi] C Series

Drive Belt, Tensioner Bearing and Fan Hub

Inspection



Wrench Size: 3/8 Inch Square Drive


Remove the drive belt and complete the following steps:

- Inspect the drive belt for damage.




Drive Belt, Tensioner Bearing and Fan Hub Page 6-11





NOTE: The tensioner pulley should rotate freely.

- Check the tensioner bearing.



NOTE: The fan hub should rotate without any wobble or excessive end play.

- Check the fan hub bearing.

Maximum End Play: 0.15 mm [0.006 in.]

Maintenance Procedures at 38,000 Kilometers [24,000 Mi]
C Series

3/8 Inch Square Drive, 13 mm

Install the drive belt.


Service Tip: If difficulty is experienced installing the drive belt (the belt seems too short), position the belt over the grooved pulleys first and then, while holding the tensioner up, slide the belt over the water pump pulley.

NOTE: After the tensioner arm has been raised, check the torque of the tensioner capscrew.

Torque Value: 43 N•m [32 ft-lb]



Drive Belt, Tensioner Bearing and Fan Hub
Page 6-13



Section 7 - Maintenance Procedures at 77,000 Kilometers [48,000 Miles], 2000 Hours or 2 Years

Section Contents

	Page
Air Compressor	7-9
Air Compressor Discharge Inspection	7-10
Air Compressor Intake Inspection	7-12
Inspection	7-9
Cooling System Maintenance	7-3
Coolant Draining	7-3
Coolant System Filling.....	7-7
Coolant System Flushing.....	7-4
General Information	7-2
Vibration Damper	7-8
Inspection	7-8


Maintenance Procedures at 77,000 Km [48,000 Mi.] C Series

Cooling System Maintenance Page 7-3


Cooling System Maintenance


Coolant Draining

Warning: Wait until the temperature is below 50°C [122°F] before removing the coolant system pressure cap. Failure to do so can cause personal injury from heated coolant spray.




Drain the cooling system by opening the drain valve on the radiator and engine lubricating oil cooler. A drain pan with a capacity of 25 liters [27 U.S. quarts] will be adequate in most applications.





Check for damaged hoses and loose or damaged hose clamps. Replace as required. Check the radiator for leaks, damage and build up of dirt. Clean and repair as required.



Coolant System Flushing

Fill the system with a mixture of sodium carbonate and water (or a commercially available equivalent).

NOTE: Use 0.5 kilogram [1.0 pound] of sodium carbonate for every 23 liters [6.0 U.S. gallons] of water.




Caution: Do not install the radiator cap. The engine is to be operated without the radiator cap for the coolant system flushing process.

Maintenance Procedures at 77,000 Km [48,000 Mi.] C Series

Caution: During filling, air must be vented from the engine coolant passages. Open the engine venting petcock and the petcock on the aftercooler for aftercooled engines. The system must be filled slowly to prevent air locks. Wait 2 to 3 minutes to allow air to be vented, then add mixture to bring the level to the bottom of the radiator filler neck.





Cooling System Maintenance Page 7-5



Operate the engine for 5 minutes with the coolant temperature above 80°C [176°F].

Shut the engine off, and drain the cooling system.






Fill the cooling system with clean water.

NOTE: Be sure to vent the engine and aftercooler for complete filling.

NOTE: Do not install the radiator cap or the new coolant filter.



Operate the engine for 5 minutes with the coolant temperature above 80°C [176°F].

Shut the engine off, and drain the cooling system.

NOTE: If the water being drained is still dirty, the system must be flushed again until the water is clean.

Maintenance Procedures at 77,000 Km [48,000 Mi.] C Series

Coolant System Filling

Caution: Never use water alone for coolant. Damage from corrosion can be the result of using water alone for coolant.


NOTE: A 50 percent mixture of antifreeze and water **must** be premixed before filling the system. The ability of antifreeze to remove heat from the engine is not as good as water, so pouring antifreeze into the engine first could contribute to an over heated condition before the liquids are completely mixed.


Close all drain valves and fill the system. Use a mixture of 50 percent water and 50 percent ethylene glycol antifreeze to provide freeze protection to -36°C [-34°F].

Coolant Capacity (Engine Only)		
Liter		U.S. Quarts
10.1	6C8.3	10.5
10.1	6CT8.3*	10.5
12.3	6CTA8.3	13.0

* Same capacity for charge air cooled engines.

Use the amount of DCA4 corrosion inhibitor given in Section V to protect the cooling system.





Warning: Wait until the coolant temperature is below 50°C [122°F] before removing the pressure cap. Failure to do so can result in personal injury from heated coolant spray.



Caution: During filling, air must be vented from the engine coolant passages. Open the engine venting petcock and the petcock on the aftercooler for aftercooled engines. The system must be filled slowly to prevent air locks. Wait 2 to 3 minutes to allow air to be vented, then add coolant to bring the level to the bottom of the radiator filler neck.



Install the pressure cap. Operate the engine until it reaches a temperature of 80°C [176°F], and check for coolant leaks and add coolant as necessary.




Vibration Damper

Inspection




Check the index lines (A) on the damper hub (B) and the inertia member (C). If the lines are more than 1.59 mm [1/16 inch] out of alignment, replace the damper.



Maintenance Procedures at 77,000 Km [48,000 Mi.] C Series

Inspect the rubber member for deterioration. If pieces of rubber are missing or if the elastic member is more than 3.18 mm [1/8 inch] below the metal surface, replace the damper.


NOTE: Also look for forward movement of the damper ring on the hub. Replace the damper if any movement is detected.




Air Compressor

Inspection

NOTE: All air compressors have a small amount of lubricating oil carry over which lubricates the piston rings and moving parts. When this lubricating oil is exposed to normal air compressor operating temperatures over a period of time, the lubricating oil will form varnish or carbon deposits. If the following inspections are **not** done, the air compressor piston rings will be affected by high operating temperatures and pressures and will **not** seal correctly.






Air Compressor Discharge Inspection

Drain the air system wet tank to release the system air pressure. Remove the air discharge line from the air compressor.



NOTE: The air discharge line is located in the engine compartment. The air discharge line is located in the engine compartment.




Measure the total carbon deposit thickness inside the air discharge line as shown. If the total carbon deposit ($X + X$) exceeds 2 mm [1/16-inch], clean and inspect the cylinder head, the valve assembly, and the discharge line. Replace if necessary. Contact your Cummins Authorized Repair Location for procedures.

Maintenance Procedures at 77,000 Km [48,000 Mi.] C Series


If the total carbon deposit exceeds specifications, continue checking the air discharge line connections up to the first tank until total carbon deposit is less than 2 mm [1/16-inch]. Clean or replace any lines or connections that exceed this specification.




Air Compressor Page 7-11



Inspect any air driers, spitter valves, pressure relief valves, and alcohol injectors for carbon deposits or malfunctioning parts. Inspect for air leaks. Maintain and repair the parts according to the manufacturer's specifications.






Air Compressor Intake Inspection



Warning: Hold the unloader valve down when removing the capscrews. Personal injury can result from the sudden release of the spring-loaded unloader valve.



Remove the capscrews, the lock washers, and the flat washers that secure the unloader valve assembly to the air compressor cylinder head cover. Remove the unloader valve assembly and the spring from the cylinder head and the cover.




Visually inspect the unloader valve for carbon buildup. If carbon or heavy varnish is present, remove, clean, and inspect the compressor head and the valve assembly. Replace parts as necessary. Contact your nearest Cummins Authorized Repair Location for procedures.



Maintenance Procedures at 77,000 Km [48,000 Mi.] C Series


NOTE: The open side of the rectangular seal **must** face the top of the unloader body.

If the unloader valve is clean or only lightly varnished, install a new o-ring on the unloader body and a new rectangular seal inside the unloader body cavity.



Lubricate the unloader cap with anti-seize compound. Lubricate the unloader body o-ring with clean 15W-40 engine lubricating oil. Assemble the unloader assembly to the cylinder head cover. Tighten the capscrews.

Torque Value: 14 N•m [10 ft-lb]



Section D - System Diagrams


Section Contents

	Page
Air System	D-10
Coolant System	D-8
Fuel System	D-3
General Information	D-2
Lubricating Oil System	D-4
Lubrication for the Overhead	D-7
Lubrication for the Power Components	D-6
Lubrication for the Turbocharger	D-5


Section D - System Diagrams C Series

Fuel System Page D-3


Fuel System




Lubricating Oil System




Lubrication for the Turbocharger




Lubrication for the Power Components




Lubrication for the Overhead




Coolant System



Coolant System



Air System



Section A - Adjustment, Replacement and Repair

Section Contents

	Page
Aftercooler and Gasket	A-60
Replacement	A-60
Air System Repair Summary	A-56
Alternator	A-89
Replacement	A-89
Belt Tensioner	A-7
Replacement	A-7
Charge Air Cooler	A-64
Intake Manifold Pressure - Check	A-64
Intake Manifold Temperature - Checking	A-64
Leak Check	A-66
Coolant Thermostat	A-15
Replacement	A-15
Cooling System Repair Summary	A-6
Drive Belt	A-7
Replacement	A-7
Electrical System Repair Summary	A-87
Exhaust Manifold and Gaskets	A-75
Replacement	A-75
Fan Pulley	A-9
Replacement	A-9

	Page
Fuel Drain Manifold	A-32
Replacement	A-32
Fuel Filter Head Adapter	A-26
Replacement	A-26
Fuel Injection Pump	A-40
Replacement	A-40
Fuel Shutoff Solenoid	A-37
Replacement	A-37
RQVK Governor Fuel Shutoff Solenoid	A-39
RSV Governor Fuel Shutoff Solenoid	A-38
Fuel System Components	A-24
Cleaning	A-24
Fuel System Repair Summary	A-23
Fuel Transfer Pump	A-27
Replacement	A-27
High Pressure Fuel Lines	A-29
Replacement	A-29
Venting	A-31
Injection Pump - Idle Speed Adjustment	A-53
RQV and RQVK Governor	A-55
RSV Governor	A-53
Injectors	A-33
Replacement	A-33
Intake Air Piping	A-57
Replacement	A-57

Section A - Adjustment, Replacement and Repair C Series

Page A-3

	Page
Intake Manifold Cover and Gasket	A-58
Replacement	A-58
Low Pressure Fuel Line	A-24
Replacement	A-24
Lubricating Oil Cooler Element and Gasket	A-82
Replacement	A-82
Lubricating Oil Pressure Regulator, Valve and Spring	A-79
Replacement	A-79
Lubricating Oil System Repair Summary	A-78
Lubricating Oil Thermostat	A-80
Replacement	A-80
Repair Procedures	A-4
Repair Tools Required	A-5
Starting Motor	A-88
Replacement	A-88
Turbocharger	A-66
Replacement	A-66
Water Pump	A-10
Replacement	A-10

Repair Procedures

The various repair procedures in this section have been organized by engine system. The summary statement of the steps and the tools needed for the replacement of a component, provided at the beginning of each group, will allow you to quickly assess the size of the task.

Follow the appropriate, illustrated steps to complete the repairs.

Section A - Adjustment, Replacement and Repair C Series

Repair Tools Required Page A-5

Repair Tools Required

Sockets


10mm
12mm
13mm
15mm
17mm
18mm
19mm
22mm
27mm

Wrenches

8mm
10mm
13mm
15mm
17mm (open end)
19mm
22mm
24mm


Other

Allen Wrench (8mm)
Breaker Bar (3/8 in. sq. drive)
Flat Screwdriver
Ratchet (3/8 in. sq. drive)
Ratchet (1/2 in. sq. drive)
Filter Wrenches (75-80mm, 90-95mm, and 118-131mm)
T-Bar Puller (75 mm)
Torque Wrench
Pliers
Engine Barring Gear, Part No. 3377371



13 mm

Remove the belt tensioner from the bracket.



13 mm

Install the belt tensioner.

Torque Value: 43 N•m

[32 ft-lb]



Section A - Adjustment, Replacement and Repair
C Series

Fan Pulley
Page A-9

Fan Pulley

Replacement

Preparatory Steps:

- Remove the drive belt.


NOTE: Loosen the capscrews before removing the belt and torque the capscrews after the belt is installed.

13 mm

Remove the four capscrews, fan and spacer. Replace the fan pulley.

Torque Value: 24 N•m


[18 ft-lb]



Water Pump Replacement

Preparatory Steps:

- Drain the coolant.
- Remove the drive belt.



10 mm, 19 mm


Remove the alternator link.




Section A - Adjustment, Replacement and Repair C Series


10 mm

Remove the water pump.




Clean the sealing surface on the cylinder block.





Install a new o-ring into the groove in the water pump.



10 mm, 19 mm

Install the water pump and alternator link.



Torque Value:

(Water Pump) 24 N•m [18 ft-lb]

(Alternator Link) 43 N•m [32 ft-lb]




Section A - Adjustment, Replacement and Repair C Series

3/8 inch Square Drive


Lift the tensioner arm and pulley to install the drive belt.


NOTE: The belt tensioner is spring loaded and must be pivoted away from the belt. Pivoting in the wrong direction can result in damage to the belt tensioner.



Water Pump Page A-13

Caution: During filling, air must be vented from the engine coolant passages. Open the engine vent petcock. Also, be sure to open the petcock on the aftercooler for aftercooled engines. The system must be filled slowly to prevent air locks. Wait 2 to 3 minutes to allow air to be vented, then add coolant to bring the level to the bottom of the radiator filler neck.





Caution: Never use water alone for coolant. Damage from corrosion can be the result of using water alone for coolant.

NOTE: A 50 percent mixture of antifreeze and water **must** be premixed before filling the system. The ability of antifreeze to remove heat from the engine is not as good as water, so pouring antifreeze into the engine first could contribute to an over heated condition before the liquids are completely mixed.

Close all drain valves and fill the system. Use a mixture of 50 percent water and 50 percent ethylene-glycol type antifreeze to provide freeze protection to -36°C [-34°F].

Coolant Capacity (Engine Only)

Liter		U.S. Quarts
10.1	6C8.3	10.5
10.1	6CT8.3*	10.5
12.3	6CTA8.3	13.0

* Same capacity for charge air cooled engines.




Use the amount of DCA4 corrosion inhibitor given in Section V to protect the cooling system.

Section A - Adjustment, Replacement and Repair C Series

Install the pressure cap. Operate the engine until it reaches a temperature of 80°C [176°F], and check for coolant leaks.




Coolant Thermostat Page A-15



Coolant Thermostat Replacement


Preparatory Steps:

- Drain 2 litres (2.1 U.S. Quarts) of coolant.
- Remove the radiator hose from the outlet connection.
- Remove the drive belt.



19 mm

Loosen the alternator link cap screw.



18 mm, 19 mm

Remove the alternator mounting bolts and nuts. Lower the alternator.




Section A - Adjustment, Replacement and Repair
C Series


Coolant Thermostat
Page A-17


10 mm

Remove the capscrews from the thermostat housing and water outlet connection. Remove the water outlet connection.




Remove the thermostat housing and belt tensioner assembly.





Remove the thermostats and clean the gasket surfaces.


NOTE: Do not let any debris fall into the thermostat cavity when cleaning gasket surfaces.




Install the new thermostats.


Section A - Adjustment, Replacement and Repair C Series

Position a new gasket over the thermostats.




Position the thermostat housing and belt tensioner over the thermostats and gasket.





Make sure the gasket is aligned with the cap screw holes.
Install the cap screws and use fingers to tighten.



10 mm

Install the water outlet connection.



Tighten all cap screws.



Torque Value: 24 N•m [18 ft-lb]

Section A - Adjustment, Replacement and Repair
C Series


18 mm, 19 mm

Position the alternator and install the mounting bolts and nuts.

Torque Value:

(Alternator Mounting) 77 N•m [57 ft-lb]

(Alternator Link) 43 N•m [32 ft-lb]





3/8 inch Square Drive

Install the drive belt.

NOTE: After raising the tensioner arm to remove/install the belt, check the torque on the tensioner cap screw.

Torque Value: 43 N•m [32 ft-lb]





Fill the cooling system. Refer to page 7-7. Operate the engine and check for leaks.

NOTE: Be sure to vent the engine and aftercooler during fill.

Section A - Adjustment, Replacement and Repair
C Series

Fuel System Repair Summary
Page A-23

Fuel System Repair Summary

Component To Be Replaced	Tools
Fuel Transfer Pump	10, 14, 17 and 20 mm Wrenches, 10 mm Socket
High Pressure Lines	17 mm, 19 mm Open End Wrench, 10 mm Socket and a Torque Wrench
Injector Fuel Drain Manifold	10 mm and 19 mm Wrenches, 10 mm and 19 mm Sockets, and a Torque Wrench
Injectors	17 mm, 19 mm, 10 mm, 13 mm and a Torque Wrench, 3823276 Injector Puller, Injector Bore Cleaning Brush
Injection Pump	Ratchet, 22 mm Socket, 27 mm Socket, 30 mm Socket, 75 mm T-Bar Puller (w/2 8 mm capscrews) 1/2 in. open end Wrench 15 mm Socket, 17 mm, 19 mm Wrench and a Torque Wrench
Fuel Solenoid	8 mm, 10 mm Wrench
Fuel Filter Head	24 mm, 75-80 mm and 90-95 mm Filter Wrench

Preparatory Steps

Clean debris.

Clean debris.


Clean debris.

Disconnect the high pressure lines and fuel drain manifold.

Remove high pressure lines, supply line, disconnect fuel return line, AFC air line and external oil line.

Label and disconnect wiring.

Clean debris.



Fuel System Components

Cleaning



Thoroughly clean all fittings and components before removal. Make sure that the debris, water, steam or cleaning solution does not reach the inside of the fuel system.

Low Pressure Fuel Line

Replacement


Preparatory Step:

- Clean debris from fittings.

Section A - Adjustment, Replacement and Repair C Series

14 mm, 17 mm, 20 mm

Disconnect the fuel line from the fuel transfer pump and fuel filter head. Use two wrenches to disconnect the line from the fuel transfer pump.




Low Pressure Fuel Line Page A-25

14, 17 mm, 20 mm

Install the fuel line to the fuel transfer pump and fuel filter head. Use two wrenches to tighten the connection to the fuel transfer pump. Do not overtighten. Fuel leak can result from overtightening.

Torque Value: 24 N•m [18 ft-lb]




Fuel Filter Head Adapter

Replacement

Preparatory Steps:

- Clean debris.
- Remove fuel filters.



24 mm

Remove the retaining nut, fuel filter head adapter and sealing washers.



Install in the reverse order of removal.



Torque Value: 32 N•m [24 ft-lb]



Section A - Adjustment, Replacement and Repair C Series

Fuel Transfer Pump Page A-27

Fuel Transfer Pump


Replacement


Preparatory Steps:

- Clean debris.
- Disconnect the fuel lines.


10 mm

Remove the fuel transfer pump.





Clean the fuel transfer pump mounting surface on the cylinder block.



10 mm

Install a new gasket and the fuel transfer pump.



Connect the fuel lines.



Torque Value: 24 N•m

[18 ft-lb]

Section A - Adjustment, Replacement and Repair C Series

High Pressure Fuel Lines Page A-29

High Pressure Fuel Lines

Replacement


Preparatory Steps:


- Clean debris.

8 mm, 10 mm, 17 mm and 19 mm

NOTE: If individual high pressure fuel lines are to be replaced, remove the support clamp from the set of lines containing the line to be replaced.

Disconnect the high pressure fuel line(s) from the injectors. Be sure to protect the injector inlet from debris.





17 mm (PES.A, PES.MW), 19 mm (PES.P)

Disconnect the high pressure fuel line(s) from the fuel injection pump. Be sure to protect the delivery valves from debris.

NOTE: Reinstall the support clamp in the original position and make sure the high pressure fuel lines do not contact each other or another component. **Do not bend the fuel lines.**

Use your hand to install the high pressure fuel lines and support clamps in the reverse order of removal. Then, tighten the line fittings and clamps.

Torque Value:

(Line Fittings) 30 N•m [22 ft-lb]

(Support Clamp) 6 N•m [4 ft-lb]


Section A - Adjustment, Replacement and Repair C Series

Venting


17 mm (PES.A, PES.MW), 19 mm (PES.P)

Warning: The pressure of the fuel in the line is sufficient to penetrate the skin and cause serious bodily harm.

Loosen the high pressure fuel line fittings at the injectors, and crank the engine to allow entrapped air to bleed from the fuel lines. Tighten the high pressure fuel line fittings to the torque value given above.



Start the engine and vent one high pressure fuel line at a time until the engine runs smoothly.




Fuel Drain Manifold

Replacement

Preparatory Steps:

- Clean debris.



10 mm

Remove the drain line banjo capscrew from the fuel filter head.




Section A - Adjustment, Replacement and Repair C Series

10 mm

Remove the drain line banjo capscrews from the injectors.
Install the manifold in the reverse order of removal.

Torque Value: 9 N•m [80 in-lb]




Injectors Page A-33

Injectors

Replacement


Preparatory Steps:

- Thoroughly clean around the injectors.
- Disconnect the high pressure fuel lines.
- Disconnect the fuel drain manifold.



10 mm (PES.A, PES.MW), (PES.P), Part No. 3823276 Injector Puller

Remove the injectors.



Part No. 3822510, Injector Bore Brush


Clean the injector nozzle bore.

Section A - Adjustment, Replacement and Repair C Series


Lubricate the sealing surface of the injector sleeve with anti-seize compound. Assemble the injector, injector sleeve, a new copper sealing washer and the holddown clamp.


Use only one washer.

Service Tip: A light coat of clean 15W40 engine oil between the washer and injector can help to keep the washer from falling during installation.



Install the injector, injector sleeve, copper sealing washer and hold down clamp into the injector bore. The injector fuel return connection **must** be toward the valve cover.






10 mm (PES.A, PES.MW), (PES.P)

Install the injector holddown cap screw.



Torque Value: 24 N•m [18 ft-lb]



10 mm

Install the fuel drain manifold.



Torque Value: 9 N•m [80 in-lb]




Section A - Adjustment, Replacement and Repair C Series

17 mm (PES.A, PES.MW), 19 mm (PES.P)

Install the high pressure fuel lines.

Torque Value: 30 N•m [22 ft-lb]




Fuel Shutoff Solenoid Page A-37

Fuel Shutoff Solenoid Replacement

Preparatory Steps:

- Label and disconnect the wiring.



RSV Governor Fuel Shutoff Solenoid

Removing

Cylinder Block Mounted

10 mm

Remove the two mounting capscrews and remove the solenoid from the bracket.

1. Synchro-start
2. Trombetta

Installing


10 mm

NOTE: Make sure the acorn nut is tightened to be snug on the fuel shutoff solenoid shaft (Synchro-start only).

Install the new fuel shutoff solenoid to the bracket and connect the wires. Make sure the wiring harness on the Trombetta solenoid is installed in the 6:00 o'clock position.

Torque Value: 10 N•m [84 in-lb]

1. Synchro-start
2. Trombetta



Section A - Adjustment, Replacement and Repair C Series

Activate the switch and check the plunger travel.


1. Synchro-start

A = 86.6 mm [3.4 in.]
B = 60.2 mm [2.4 in.]

2. Trombetta

A = 91.4 mm [3.6 in.]
B = 63.5 mm [2.5 in.]

The plunger **must** be retracted when the fuel shutoff solenoid is activated to the **RUN** position "B". The fuel shutoff solenoid **must** operate without binding.



RQVK Governor Fuel Shutoff Solenoid


Removing and Installing


8 mm

Remove the hitch pin clip, the mounting capscrews and the fuel shutoff solenoid.

Install the new solenoid in reverse order of removal and connect the wires.

Torque Value: 10 N•m [84 in-lb]





10 mm, 16 mm

Adjust the solenoid linkage as necessary so that the plunger is magnetically held in with the shutoff lever in the absolute full run position. Turn the large hex nut on the end of the plunger to make adjustments.

Fuel Injection Pump Replacement

Preparatory Steps:

- Clean debris.
- Remove all fuel lines.
- Remove control linkage.
- Remove fuel shutoff solenoid.
- Remove the AFC air line.
- Remove the governor oil line.


Section A - Adjustment, Replacement and Repair C Series

Removing

Part No. 3377371 Engine Barring Gear

Locate TDC for cylinder number 1. Push the timing pin into the hole in the camshaft gear while slowly rotating the crankshaft.


Caution: Be sure to disengage the timing pin after locating TDC to prevent damage to the timing pin.




22 mm (PES.A Pump), 27 mm (PES.MW Pump), 30 mm (PES.P Pump)

Remove the gear cover access cap.


Remove the nut and washer from the fuel injection pump shaft.





75 mm T-Bar Puller

Pull the fuel injection pump drive gear loose from the shaft.



10 mm, 15 mm

Remove the four mounting nuts and the capscrews that fasten the fuel injection pump support to the cylinder block.

Remove the rear support bracket for the PES6P fuel injection pump.

Remove the fuel injection pump.




Section A - Adjustment, Replacement and Repair C Series

Installing

Part No. 3377371 Engine Barring Gear


Make sure the engine has cylinder number 1 at TDC.




Fuel Injection Pump - Timing

The fuel injection pump also has a timing pin (1), located in the governor housing, to position the fuel injection pump shaft to correspond with TDC for cylinder number 1. After the fuel injection pump is installed, the timing pin is to be reversed and stored in the housing (2).


NOTE: The industrial governor is shown in the illustration. The procedure is the same for automotive governors.





24 mm

Remove the timing pin access plug.




Remove the timing pin.

**Section A - Adjustment, Replacement and Repair
C Series**


If the timing tooth is not aligned with the timing pin hole, rotate the pump shaft until the timing tooth aligns.


**Fuel Injection Pump
Page A-45**



Reverse the position of the timing pin so the slot of the timing pin will fit over the timing tooth in the fuel injection pump.


Install and secure the timing pin with the access plug.





Make sure the o-ring seals for the fill orifice (A) and pilot (B) are correctly installed on the fuel injection pump and are not damaged.

Lubricate the mounting flange with clean 15W-40 engine lubricating oil.




NOTE: The oil feed o-ring (A) for PES.P fuel injection pump will be located in the gear housing.


Section A - Adjustment, Replacement and Repair
C Series


Fuel Injection Pump
Page A-47

Slide the fuel injection pump shaft through the drive gear and position the fuel injection pump flange onto the mounting studs. Use your fingers to tighten the mounting nuts.



Use your fingers to tighten the capscrews for the support bracket.






15 mm

Tighten the mounting nuts.



Torque Value: 43 N•m [32 ft-lb]



10 mm (PES6P Fuel Injection Pump)

Tighten the capscrews for the rear support bracket.

Torque Value: 24 N•m [18 ft-lb]


Section A - Adjustment, Replacement and Repair
C Series

22 mm (PES.A Pump), 27 mm (PES.MW Pump),
30 mm (PES.P Pump)


Install the fuel injection pump retaining nut and washer.


Initial Torque Value: 11 N•m [108 in-lb]

NOTE: Do not exceed the torque value given. This is not the final torque value for the fuel injection pump retaining nut.



Disengage the engine timing pin.






24 mm

Remove the fuel injection pump timing pin plug. Reverse the position of the timing pin and install the pin, plug, and sealing washer.

Torque Value: 15 N•m [11 ft-lb]



22 mm, 27 mm or 30 mm

Tighten the fuel injection pump drive nut.

Torque Value:

PES.A Pump, 93 N•m [68 ft-lb]

PES.MW Pump, 105 N•m [77 ft-lb]

PES.P Pump, 165 N•m [122 ft-lb]



Install the gear cover access cap hand tight.

Section A - Adjustment, Replacement and Repair
C Series

Fuel Injection Pump
Page A-51

17 mm (PES.A, PES.MW), 19 mm (PES.P)

Install the high pressure lines to the fuel pump.

Install the fuel supply and fuel return lines.


NOTE: If removed, reinstall the support clamp in the original position and make sure the high pressure lines do not contact each other or another component.

Torque Value:

(Line Fittings) 30 N•m [22 ft-lb]

(Support Clamp) 6 N•m [48 in-lb]

(Fuel Supply and Fuel Return Banjo) 24 N•m [18 ft-lb]





Caution: If a replacement or repaired pump was installed, be sure to fill the governor housing with clean 15W40 engine lubricating oil before starting the engine. Failure to do so will result in damage to the governor fly weights.



Governor Housing Oil Capacity

ml		fl. oz.
450	RSV	13.5
750	RQV, RQVK	22.5





Fuel Injection Pump - Venting


10 mm, 17 mm

The PES.MW pump **must** be vented after installation. Loosen the vent screw located near the front on the side nearest to the engine. Place the fuel control in the **RUN** position. Crank the engine so air can bleed from the fuel injection pump, then tighten the vent screw.

NOTE: Earlier PES.MW fuel injection pumps were not equipped with a vent screw. Remove the large plug from the location described above to vent the fuel injection pump. PES.A pumps are self venting.



Torque Value: 9 N•m [80 in-lb]



Vent each high pressure fuel line separately until the engine runs smoothly. Tighten the high pressure fuel lines.

Torque Value: 30 N•m [22 ft-lb]


Section A - Adjustment, Replacement and Repair C Series

Injection Pump - Idle Speed Adjustment

RSV Governor

Idle adjustment for **industrial** engines requires the setting of both the low idle screw (1) and the bumper spring screw (2).


Injection Pump - Idle Speed Adjustment Page A-53




19 mm Screwdriver and Tachometer

First, loosen the locknut and back out the bumper spring screw until there is no change in engine speed.

NOTE: The speed should drop 20-30 RPM as the bumper spring screw is backed out.






13 mm Screwdriver and Tachometer

Loosen the locknut and adjust the idle screw to 20-30 RPM less than the desired speed. Turn the idle screw **counterclockwise** to decrease RPM; **clockwise** to increase RPM. Tighten the idle screw locknut.



Torque Value: 8 N•m [72 in-lb]



Turn the bumper spring **clockwise** until the desired idle speed is obtained. Tighten the locknut.

Torque Value: 8 N•m [72 in-lb]

Section A - Adjustment, Replacement and Repair C Series

RQV and RQVK Governor


10 mm Screwdriver and Tachometer

Idle adjustment on **automotive** fuel injection pumps requires setting of the idle adjustment screw.

Loosen the locknut and turn the idle adjustment screw **counterclockwise** to raise the RPM; **clockwise** to decrease the idle speed. Tighten the locknut.

Torque Value: 8 N•m [72 in-lb]

Injection Pump - Idle Speed Adjustment Page A-55



Air System Repair Summary

Component To Be Replaced	Tools	Preparatory Steps*
Intake Air Piping	8 mm Socket, Common Screwdriver and Torque Wrench	
Intake Manifold Cover and Gasket	10 mm Socket	Disconnect cold starting aid, if used, and air piping.
Aftercooler and Gasket	8 mm, 10 mm Socket	Disconnect cold starting aid if used, remove air crossover tube and drain coolant.
Turbocharger and/or Gasket	10 mm, 15 mm, 16 mm, 7/16-Inch Wrenches	Disconnect intake and exhaust piping.
Exhaust Manifold and/or Gasket	15 mm Socket	Disconnect intake and exhaust piping, and remove the turbocharger.

*Removal of some chassis parts may be necessary to gain access to some engine components. Follow the equipment manufacturer's procedures and precautions for removing chassis parts.

Section A - Adjustment, Replacement and Repair C Series

Intake Air Piping

Replacement

8 mm or Screwdriver

Loosen the hose clamps and remove the air piping.



8 mm or Screwdriver

Use new hose piping and clamps as required.

Tighten the hose clamps.

Refer to the manufacturers specifications for the correct torque value.


Intake Air Piping Page A-57



Intake Manifold Cover and Gasket Replacement

Preparatory Steps:

- Disconnect the cold starting aid, if used.
- Remove the air crossover tube.
- Remove the high pressure fuel lines



10 mm


Remove the air intake manifold cover and gasket.



Section A - Adjustment, Replacement and Repair C Series

Clean the sealing surface.


NOTE: Keep the gasket material and any other material out of the air intake manifold.




10 mm, 19 mm

Install the air intake manifold cover and a new gasket.
Install the high pressure fuel lines.

Torque Value: 24 N•m [18 ft-lb]





Assemble the intake piping and connect the cold starting aid if used. Vent the high pressure fuel lines.

Aftercooler and Gasket

Replacement


Preparatory Steps:

- Disconnect the cold starting aid, if used.
- Remove the air crossover tube.
- Drain 2 litres (2.1 U.S. Quarts) of coolant.
- Remove the high pressure fuel ines.

Section A - Adjustment, Replacement and Repair C Series

8 mm


Remove the coolant supply tube (1) and the coolant return tube (2) (off highway engines).




Aftercooler and Gasket Page A-61

10 mm


Remove the aftercooler housing and gasket.





Clean the sealing surface.

NOTE: Keep the gasket material and any other material out of the air intake.



10 mm, 19 mm

Install the aftercooler housing and a new gasket.



Install the high pressure fuel lines.



Torque Value: 24 N•m [18 ft-lb]


Section A - Adjustment, Replacement and Repair C Series

Aftercooler and Gasket Page A-63

8 mm


Install the coolant supply tube (1) and coolant return tube (2). Install the air crossover tube.


Torque Value: 8 N•m [72 in-lb]



Caution: Be sure to open the engine and aftercooler vents to allow air to escape as the system is filled. Refer to the procedure given on page 7-7. Vent the high pressure fuel lines.

Fill the coolant system with a mixture of 50% water and 50% ethylene-glycol type antifreeze.





Charge Air Cooler

Intake Manifold Pressure - Check



Install pressure gauge, Part No. ST-1273, to the fitting in the turbocharger outlet.



Install another pressure gauge, Part No. ST-1273, in the intake manifold.



Operate the engine at rated RPM and load. Record the readings on the two gauges.



If the differential pressure is greater than 21 kPa [3 psi], check the charge air cooler for plugging. Clean or replace if necessary. Refer to Procedure (3-07).

Intake Manifold Temperature - Checking




Install a temperature gauge in the intake manifold.



Lock the fan drive in the ON mode to prevent erratic test results. This can be done by installing a jumper across the temperature switch or supplying shop air to the fan. Refer to the fan drive manufacturer for lock-up procedure.

NOTE: Some trucks have a manual switch that will lock on the fan.




Section A - Adjustment, Replacement and Repair C Series

Operate the engine at rated RPM and load. Record the intake manifold temperature.

Measure the ambient temperature at least 60.96 cm [2.0 feet] in front of the vehicle.

The maximum temperature differential **must not** be greater than 7°C [45°F].


If the temperature differential is greater than 7°C [45°F], check the charge air cooler for dirt and debris on the fins, and clean as necessary. If the problem still exists, check the cooler for internal contamination or plugging.




To check the charge air cooler for cracked tubes or header, remove the inlet and outlet hoses from the cooler.

Remove the charge air cooler.

Install a cap over the outlet side of the cooler. Install a pressure gauge and a shop air supply line to the inlet side of the cooler.





Leak Check

Apply 276 kPa [40 psi] of air pressure to the cooler. If the pressure drop is 35 kPa [5 psi] or less in 15 seconds, the cooler is okay.

If the pressure drop is greater than 35 kPa [5 psi] in 15 seconds, the charge air cooler **must** be repaired or replaced. Refer to the CAC manufacturer for repair instructions.

NOTE: A leak tank can be used to locate the air leak.

Turbocharger

Replacement


Preparatory Steps:

- Remove the air intake piping.
- Disconnect the intake and exhaust piping.
- Disconnect the wastegate actuator line.

Section A - Adjustment, Replacement and Repair C Series


10 mm


Remove the capscrews from the oil drain tube.



16 mm


Remove the oil supply line.





15 mm and 11 mm

Remove the exhaust clamp, turbocharger, and gasket.




Clean the sealing surface. Inspect the sealing surface and mounting studs for damage.

Section A - Adjustment, Replacement and Repair
C Series


Caution: If the turbocharger is not to be immediately replaced, cover the opening to prevent any material from falling into the manifold.




Turbocharger
Page A-69



Install a new gasket and apply anti-seize compound to the mounting studs.






15 mm

Install the turbocharger.



Torque Value: 32 N•m [24 ft-lb]



11 mm

If required, loosen the turbine housing capscrews and position the bearing housing to install the turbocharger drain tube.




Section A - Adjustment, Replacement and Repair
C Series

Turbocharger
Page A-71

10 mm


Install the hose and clamps on the turbocharger drain tube loosely. Install the drain tube and gasket on the turbocharger.


Torque Value: 24 N•m [18 ft-lb]



Position the turbocharger drain hose to connect the drain tubes; tighten the clamps.

Torque Value: 5 N•m [44 in-lb]






11 mm, Punch, Hammer

If loosened, tighten the turbine housing cap screws.

Torque Value: 11 N•m [100 in-lb]



11 mm

If required, loosen the compressor housing and position the housing to align with the air crossover tube.



Section A - Adjustment, Replacement and Repair C Series


Turbocharger
Page A-73

11 mm, Plastic Hammer

Tighten the band clamp. Tap around the clamp with a plastic hammer and tighten again.


Torque Value: 8 N•m [71 in-lb]


NOTE: Effective Oct. 1, 1990 all Holset Turbochargers use silver plated nuts with the v-band clamp. The silver plated nuts require a **lower** torque than the stainless steel nut to provide the same v-band clamp load.



Caution: New turbochargers must be prelubricated before start-up to prevent internal damage.

Pour 50 to 60 cc [2 to 3 ounces] of clean 15W-40 engine lubricating oil into the oil supply fitting. Rotate the turbine wheel to allow the lubricating oil to enter the bearing housing.






Install the exhaust outlet connection.

Do not tighten the two mounting capscrews until the band clamp has been tightened.

Torque Value: Band Clamp - 8 N•m [71 in-lb]
Capscrews - 43 N•m [32 ft-lb]



16 mm

Install the lubricating oil supply line.

Torque Value: 15 N•m [11 ft-lb]


Section A - Adjustment, Replacement and Repair C Series

Install the air inlet and exhaust piping. Install the waste-gate actuator line.

Operate the engine and check for leaks.




Exhaust Manifold and Gaskets Page A-75



Exhaust Manifold and Gaskets Replacement


Preparatory Steps:

- Remove the air crossover tube.
- Disconnect the air intake and exhaust piping.
- Remove the turbocharger, if used.



16 mm

Remove the exhaust manifold and gaskets.



Clean the exhaust manifold sealing surfaces.

Section A - Adjustment, Replacement and Repair
C Series


Exhaust Manifold and Gaskets
Page A-77

16 mm


Install the exhaust manifold, new gaskets and lock plates.

Torque Value: 43 N•m [32 ft-lb]

Follow the tightening sequence shown in the illustration.



Install the parts previously removed. Operate the engine and check for leaks.



Lubricating Oil System Repair Summary

Component To Be Replaced	Tools	Preparatory Steps
Oil Pressure Regulator Valve and/or Spring	22mm Socket, Ratchet and Torque Wrench	Clean debris.
Lubricating Oil Thermostat	32 mm Socket, Ratchet and Torque Wrench	Clean debris.
Oil Cooler Element and/or Gaskets	16mm Wrench, Ratchet, 10mm Socket and Torque Wrench	Drain coolant. Remove the oil filter.

Section A - Adjustment, Replacement and Repair C Series

Lubricating Oil Pressure Regulator, Valve and Spring Page A-79

Lubricating Oil Pressure Regulator, Valve and Spring


Replacement


Preparatory Steps:

- Clean debris.

32 mm

Remove the plug, spring and regulator valve.





32 mm

Clean and inspect the bore and regulator valve before assembly.

The valve must move freely in the bore.

Install the regulator, spring and plug.

Torque Value: 80 N•m [60 ft-lb]

Lubricating Oil Thermostat Replacement


Preparatory Steps:

- Clean debris

Section A - Adjustment, Replacement and Repair C Series

32 mm

Remove the lubricating oil thermostat.




32 mm

Clean and inspect the lubricating oil thermostat bore before assembly.

Install the lubricating oil thermostat.

Torque Value: 50 N•m [37 ft-lb]




Lubricating Oil Cooler Element and Gasket

Replacement

Preparatory Steps:

- Drain the coolant.
- Remove the lubricating oil filter.



Clean all debris from around the lubricating oil cooler.


Section A - Adjustment, Replacement and Repair C Series

16 mm

Remove the turbocharger oil supply line from the oil filter head.




Lubricating Oil Cooler Element and Gasket Page A-83




10 mm


Remove the oil cooler cover, element and gaskets.

NOTE: The element will contain approximately 0.7 Liters [0.75 U.S. Qts.] of lubricating oil which will drain when the cooler is removed from the engine.





Clean the oil cooler sealing surfaces.



10 mm

Assemble the lubricating oil cooler gasket, element, cooler cover gasket, lubricating oil thermostat and oil cooler cover to the cylinder block.



Install the filter head and gasket if removed.



NOTE: Be sure to remove the shipping plugs from the new cooler element.

Torque Value:

Lubricating Oil Cooler Cover Capscrews 24 N•m [18 ft-lb]

Lubricating Oil Filter Head Capscrews 24 N•m [18 ft-lb]


**Section A - Adjustment, Replacement and Repair
C Series**

16 mm

Connect the turbocharger oil supply line.


Torque Value: 15 N•m [11 ft-lb]


**Lubricating Oil Cooler Element and Gasket
Page A-85**



Install a new lubricating oil filter.

Follow the manufacturer's instructions for tightening.





NOTE: Be sure to open the engine and aftercooler vents to allow air to escape as the system is filled. Refer to the procedure given on page 7-7.



Fill the coolant system and operate the engine to check for leaks.

Stop the engine and check the coolant and lubricating oil level.

Section A - Adjustment, Replacement and Repair
C Series

Electrical System Repair Summary

Component To Be Replaced

Starting Motor

Alternator

Tools

Ratchet, 16mm Socket, 19mm Wrench, and Torque Wrench

Ratchet, 8mm, 13mm and 17mm Socket and Torque Wrench, 1/2 inch Square Drive Breaker Bar

Electrical System Repair Summary
Page A-87

Preparatory Steps

Disconnect ground cable to battery.


Disconnect ground cable to battery and remove drive belt.

Starting Motor

Replacement

Preparatory Steps:

- Disconnect the ground cable from the battery.
- Identify each electrical wire with a tag indicating location.



19 mm

Remove the battery cable from the solenoid.




Section A - Adjustment, Replacement and Repair C Series

16 mm

Remove the starting motor and spacer.

Install the starting motor in the reverse order of removal.

Torque Value: 77 N•m [57 ft-lb]




Alternator Page A-89

Alternator

Replacement

Preparatory Steps:

- Disconnect the ground cable from the battery terminal.
- Identify each electrical wire with a tag indicating location.
- Remove the drive belt.




19 mm

Remove the capscrew (A) from the alternator link.



Remove the capscrew (B) from the support bracket.



18 mm, 19 mm

Remove the alternator mounting capscrews and nuts.




Remove the alternator.

Section A - Adjustment, Replacement and Repair
C Series

Alternator
Page A-91


Position the alternator on the bracket and secure it with the mounting capscrews.


Do not tighten at this time.



Connect the alternator link to the alternator. Finger tighten.

NOTE: Make sure the alternator link is properly positioned for correct belt alignment.





15, 18, 19 mm

Tighten the alternator mounting capscrew.

Torque Value:

A = 43 N•m [32 ft-lb]

B = 24 N•m [18 ft-lb]

Install the drive belt.

Section V - Specifications and Torque Values

Section Contents

	Page
Capscrew Markings and Torque Values	V-25
Capscrew Markings and Torque Values - Metric	V-26
Coolant Recommendations	V-13, V-14
DCA4 Unit Maintenance Guide	V-15
Engine Component Torque Values	V-18
Engine Lubricating Oil Recommendations	V-8
Arctic Operation	V-12
Lubricating Oil Viscosity Recommendations	V-8
Oil Consumption	V-11
Filter Selection	V-17
Fuel Filters	V-17
Lubricating Oil Filter	V-17
Fuel Recommendations/Specifications	V-6
General Specifications	V-2
ELECTRICAL SYSTEM	V-5
Lubricants and Sealants - Engine Assembly	V-22

General Specifications

GENERAL ENGINE DATA	6C8.3	6CT8.3	6CTA8.3	C8.3
Bore - mm [in.]	-----	114 [4.49]	-----	-----
Stroke - mm [in.]	-----	135 [5.32]	-----	-----
Displacement - liter [in. ³]	-----	8.27 [504.5]	-----	-----
Engine Weight (Dry Weight)	-----	603 - 612 Kg [1330 - 1350 lb]	-----	-----
(Wet Weight)	-----	635 - 658 Kg [1400 - 1450 lbs]	-----	-----
Firing Order	-----	1-5-3-6-2-4	-----	-----
Valve Clearances	-----	-----	-----	-----
- Intake - mm [in.]	-----	0.30 [0.012]	-----	-----
- Exhaust - mm [in.]	-----	0.61 [0.024]	-----	-----
Compression Ratio	16.4:1	17.3:1	16.5:1	17.3:1*/18:1**
Rotation, viewed from the Front of the Engine	-----	Clockwise	-----	-----
Aspiration	-----	-----	-----	-----
- Naturally Aspirated	X	-----	-----	-----
- Turbocharged	-----	X	-----	-----
- Aftercooled	-----	-----	X	-----
- Charge Air Cooling (CAC)	-----	-----	-----	X

* High Torque

** Low Torque

Section V - Specifications and Torque Values C Series

General Specifications Page V-3

LUBRICATION SYSTEM	6C8.3	6CT8.3	6CTA8.3	C8.3
Lubricating Oil Pressure at Idle - (Minimum Allowable) kPa [PSI]	-----	69 [10]	-----	-----
Lubricating Oil Pressure at Rated - (Minimum Allowable) kPa [PSI]	-----	207 [30]	-----	-----
Regulating Valve Opening Pressure kPa [PSI]	-----	518 [75]	-----	-----
Differential Pressure to Open the Filter Bypass Valve - kPa [PSI]	-----	138 [20]	-----	-----
Lubricating Oil Capacity of Pan (High-Low) - Liter [U.S. Qts.]	-----	18.9 [20]	-----	-----
	-----	15.3 [16]	-----	-----
COOLING SYSTEM				
Coolant Capacity (Engine Only) - liter [U.S. Qts.]	9.9 [10.5]	9.9 [10.5]	10.9 [11.5]	9.9 [10.5]
Standard Modulating Thermostat - Range - °C [°F]	Start 83 [181]	-----	Fully Open 95 [203]	-----
Pressure Cap - kPa [PSI] Min	-----	50 [7]	-----	-----
Maximum Allowable Top Tank Temperature °C [°F]	-----	100°C [212°F]	-----	-----
Minimum Recommended Top Tank Temp. °C [°F]	-----	70°C [158°F]	-----	-----

INTAKE AIR, EXHAUST AND FUEL SYSTEM	6C8.3	6CT8.3	6CTA8.3	C8.3
Maximum Allowable Air Intake Restriction at Rated Speed and Load with Dirty Air Filter Element - mm H ₂ O [in. H ₂ O]	508 [20]	635 [25]	635 [25]	635 [25]
Maximum Allowable Exhaust Restriction at Rated Speed and Load - mm Hg [in. Hg]	-----	76 [3] 152 [6]*	-----	-----
Maximum Fuel Filter Pressure Drop Across Filters kPa [PSI]	-----	34 [5]	-----	-----
Maximum Allowable Return Line Restriction - mm Hg [in. Hg]	-----	518 [20.4]	-----	-----
Maximum Inlet Restriction to Fuel Transfer Pump mm Hg [in. Hg]	-----	100 [4]	-----	-----

* with catalyst

Section V - Specifications and Torque Values
C Series

General Specifications
Page V-5

ELECTRICAL SYSTEM

Minimum Recommended Battery Capacity

Battery Size	Ambient Temperatures			
	-18°C (0°F)		0°C (32°F)	
	Cold Cranking Amperes	Reserve Capacity * Amperes	Cold Cranking Amperes	Reserve Capacity * Amperes
12 Volt	1800	640	1280	480
24 Volt**	900	320	640	240

* The number of plates within a given battery size determine reserve capacity. Reserve capacity determines the length of time sustained cranking can occur.

** Per Battery (two 12 volt batteries in series) CCA ratings are based on -18°C [0°F].

Batteries (Specific Gravity)

Specific Gravity at 27°C [80°F]	State of Charge
1.260 - 1.280	100%
1.230 - 1.250	75%
1.200 - 1.220	50%
1.170 - 1.190	25%
1.110 - 1.130	Discharged

Fuel Recommendations/Specifications

Warning: Do not mix gasoline or alcohol with diesel fuel. This mixture can cause an explosion.

Caution: Due to the precise tolerances of diesel injection systems, it is extremely important that the fuel be kept clean and free of dirt or water. Dirt or water in the system can cause severe damage to both the fuel injection pump and the nozzles.

NOTE: The use of diesel fuel blended with lube oil is **not** acceptable for engines equipped with a catalytic converter. Automotive engines for model year 1994 and beyond are equipped with a catalyst as a part of emission control.

Use ASTM No. 2 D fuel with a minimum Cetane number of 40. No. 2 diesel fuel gives the best economy and performance under most operating conditions. Fuels with Cetane numbers higher than 40 may be needed in high altitudes or extremely low ambient temperatures to prevent misfires and excessive smoke.

At operating temperatures below 0°C [32°F], use a blend of No. 1 D and No. 2 D fuels, also known as "winterized" No. 2 D.

NOTE: No. 1 D fuel can be used, however, fuel economy will decrease.

Use low sulfur content fuel having a cloud point that is at least 10 degrees below the lowest expected fuel temperature. Cloud point is the temperature at which crystals begin to form in diesel fuel.

The viscosity of the fuel **must** be kept above 1.3 centistokes at 40°C [104°F] to provide adequate fuel system lubrication.

For a more detailed description of fuel properties, refer to Fuel For Cummins Engines, Bulletin No. 3379001-04. The following chart lists acceptable alternate fuels for MidRange engines.

Section V - Specifications and Torque Values C Series

Fuel Recommendations/Specifications Page V-7

Acceptable Alternate Fuels Component Wear/Durability		
Fuel Type	Bosch Inline Pumps	Nippondenso EP-9
NO. 1-D Diesel	OK	OK
NO. 2 Fuel Oil	OK	OK
NO. 1-K Kerosene	OK	OK
NO. 2-K Kerosene	OK	OK
Jet-A	OK	OK
Jet A-1	OK	OK
JP-5	OK	OK
JP-8	OK	OK
Jet-B	Not ok	Not ok
JP-4	Not ok	Not ok
Cite	Not ok	Not ok

NOTE: Any adjustment to compensate for reduced performance with a fuel system using alternate fuel is not warrantable.

NOTE: Wear on any mid-range fuel injection pump component attributed to the lack of lubrication in the fuel is not a warrantable repair.

Engine Lubricating Oil Recommendations

The use of quality engine lubricating oils combined with appropriate lubricating oil drain and filter change intervals is a critical factor in maintaining engine performance and durability.

Cummins Engine Company, Inc. recommends the use of a high quality SAE 15W-40 heavy duty engine lubricating oil (such as Cummins Premium Blue) which meets the American Petroleum Institute (API) performance classification CE/SG.

NOTE: CC/CD or CD/SF engine lubricating oils can be used in areas where CE oil is not yet available, but the lubricating oil change interval must be reduced to one half the interval given in the maintenance schedule.

A sulfated ash limit of 1.0 mass percent is suggested for optimum valve and piston deposit and lubricating oil consumption control. The sulfated ash **must not** exceed 1.85 mass percent.

Lubricating Oil Viscosity Recommendations

The use of multi-viscosity lubricating oil has been found to improve lubricating oil consumption control and improve engine cranking in cold temperatures while maintaining lubrication at high operating temperatures.


While 15W-40 lubricating oil is recommended for most climates, refer to the accompanying table for lubricating oil viscosity recommendations for extreme climates.

Section V - Specifications and Torque Values C Series

Engine Lubricating Oil Recommendations Page V-9

For further details and discussion of engine lubricating oils for Cummins engines, refer to Bulletin No. 3810340, Cummins Engine Oil Recommendations.

Caution: Limited use of low viscosity lubricating oils, such as 10W-30 may be used to aid in starting the engine and providing sufficient oil flow at ambient temperatures below -5°C [23°F]. However, continuous use of low viscosity lubricating oils can decrease engine life due to wear. Refer to the accompanying chart.



Is your vehicle an On-Highway application?	YES	Is your vehicle one of those below? - Regional Haul Truck - Coach Bus - Vehicle accum 8000 miles/mth. or more.	YES	<table border="1" style="width: 100%; border-collapse: collapse;"> <tr> <th colspan="4">Change Interval</th> </tr> <tr> <th>KM</th> <th>MILES</th> <th>HOURS</th> <th>MOS</th> </tr> <tr> <td>16,000</td> <td>10,000</td> <td>250</td> <td>3</td> </tr> </table>	Change Interval				KM	MILES	HOURS	MOS	16,000	10,000	250	3																																	
Change Interval																																																	
KM	MILES	HOURS	MOS																																														
16,000	10,000	250	3																																														
NO		NO																																															
<div style="display: flex; justify-content: space-between;"> <div style="width: 45%;"> <p>Use the following oil drain intervals for your application (1):</p> <table border="1" style="width: 100%; border-collapse: collapse;"> <tr> <th>VEH/EQUIP</th> <th>KM</th> <th>MILES</th> <th>HRS</th> <th>MOS</th> </tr> <tr> <td>Refuse Trk</td> <td>10,000</td> <td>6,000</td> <td>250</td> <td>3</td> </tr> <tr> <td>Mixer/Dumper</td> <td>10,000</td> <td>6,000</td> <td>250</td> <td>3</td> </tr> <tr> <td>Del. Truck</td> <td>10,000</td> <td>6,000</td> <td>250</td> <td>6</td> </tr> <tr> <td>Shuttle or Transit Bus</td> <td>10,000</td> <td>6,000</td> <td>250</td> <td>3</td> </tr> <tr> <td>School Bus</td> <td>10,000</td> <td>6,000</td> <td>250</td> <td>6</td> </tr> <tr> <td>Fire Truck</td> <td>10,000</td> <td>6,000</td> <td>250</td> <td>3</td> </tr> <tr> <td>Recreational Vehicle</td> <td>10,000</td> <td>6,000</td> <td>250</td> <td>6</td> </tr> </table> </div> <div style="width: 50%;"> <p>(1) Or whichever comes first. If your application accumulates high hours and low mileage, the change interval is determined by hours.</p> <p>Example: Transit bus and refuse trucks may average 16 Km/h [10 MPH] when used in an all urban route. Oil drain intervals in those applications are 4800 Km [3,000 mi], or less.</p> </div> </div>					VEH/EQUIP	KM	MILES	HRS	MOS	Refuse Trk	10,000	6,000	250	3	Mixer/Dumper	10,000	6,000	250	3	Del. Truck	10,000	6,000	250	6	Shuttle or Transit Bus	10,000	6,000	250	3	School Bus	10,000	6,000	250	6	Fire Truck	10,000	6,000	250	3	Recreational Vehicle	10,000	6,000	250	6					
VEH/EQUIP	KM	MILES	HRS	MOS																																													
Refuse Trk	10,000	6,000	250	3																																													
Mixer/Dumper	10,000	6,000	250	3																																													
Del. Truck	10,000	6,000	250	6																																													
Shuttle or Transit Bus	10,000	6,000	250	3																																													
School Bus	10,000	6,000	250	6																																													
Fire Truck	10,000	6,000	250	3																																													
Recreational Vehicle	10,000	6,000	250	6																																													
Is your vehicle used in a Construction, Mining or Logging Application?	YES	<p>Use the following oil drain intervals for your application (1):</p> <table border="1" style="width: 100%; border-collapse: collapse;"> <tr> <th>VEHICLE/EQUIP</th> <th>KM</th> <th>MILES</th> <th>HRS</th> <th>MOS</th> </tr> <tr> <td>Truck Crane</td> <td>10,000</td> <td>6,000</td> <td>250</td> <td>3</td> </tr> <tr> <td>Yard Spotter</td> <td>10,000</td> <td>6,000</td> <td>250</td> <td>3</td> </tr> <tr> <td>Paver</td> <td>N/A</td> <td>N/A</td> <td>250</td> <td>6</td> </tr> <tr> <td>Cranes</td> <td>N/A</td> <td>N/A</td> <td>250</td> <td>6</td> </tr> <tr> <td>Backhoe</td> <td>N/A</td> <td>N/A</td> <td>250</td> <td>6</td> </tr> <tr> <td>Dozer</td> <td>N/A</td> <td>N/A</td> <td>250</td> <td>6</td> </tr> <tr> <td>Scraper</td> <td>N/A</td> <td>N/A</td> <td>250</td> <td>6</td> </tr> <tr> <td>Skidder</td> <td>N/A</td> <td>N/A</td> <td>250</td> <td>6</td> </tr> </table>			VEHICLE/EQUIP	KM	MILES	HRS	MOS	Truck Crane	10,000	6,000	250	3	Yard Spotter	10,000	6,000	250	3	Paver	N/A	N/A	250	6	Cranes	N/A	N/A	250	6	Backhoe	N/A	N/A	250	6	Dozer	N/A	N/A	250	6	Scraper	N/A	N/A	250	6	Skidder	N/A	N/A	250	6
VEHICLE/EQUIP	KM	MILES	HRS	MOS																																													
Truck Crane	10,000	6,000	250	3																																													
Yard Spotter	10,000	6,000	250	3																																													
Paver	N/A	N/A	250	6																																													
Cranes	N/A	N/A	250	6																																													
Backhoe	N/A	N/A	250	6																																													
Dozer	N/A	N/A	250	6																																													
Scraper	N/A	N/A	250	6																																													
Skidder	N/A	N/A	250	6																																													
NO																																																	
Is your vehicle used in an Agricultural or Stationary Power Application?	YES	<p>Use the following oil drain intervals for your application (1):</p> <table border="1" style="width: 100%; border-collapse: collapse;"> <tr> <th>VEHICLE/EQUIP</th> <th>HOURS</th> <th>MONTHS</th> </tr> <tr> <td>Farm Tractors</td> <td>250</td> <td>6</td> </tr> <tr> <td>Combines</td> <td>250</td> <td>6</td> </tr> <tr> <td>Irrigation Equip.</td> <td>250</td> <td>6</td> </tr> <tr> <td>Generator Set</td> <td>250</td> <td>6</td> </tr> <tr> <td>Air Compressor</td> <td>250</td> <td>6</td> </tr> <tr> <td>Fire Pump</td> <td>250</td> <td>6</td> </tr> <tr> <td>Pleasure Boat</td> <td>250</td> <td>6</td> </tr> <tr> <td>Work Boat</td> <td>250</td> <td>3</td> </tr> </table>			VEHICLE/EQUIP	HOURS	MONTHS	Farm Tractors	250	6	Combines	250	6	Irrigation Equip.	250	6	Generator Set	250	6	Air Compressor	250	6	Fire Pump	250	6	Pleasure Boat	250	6	Work Boat	250	3																		
VEHICLE/EQUIP	HOURS	MONTHS																																															
Farm Tractors	250	6																																															
Combines	250	6																																															
Irrigation Equip.	250	6																																															
Generator Set	250	6																																															
Air Compressor	250	6																																															
Fire Pump	250	6																																															
Pleasure Boat	250	6																																															
Work Boat	250	3																																															
NO																																																	
<table border="1" style="width: 100%; border-collapse: collapse;"> <tr> <th colspan="4">Change Interval</th> </tr> <tr> <th>KM</th> <th>MILES</th> <th>HOURS</th> <th>MOS</th> </tr> <tr> <td>10,000</td> <td>6,000</td> <td>250</td> <td>3</td> </tr> </table>					Change Interval				KM	MILES	HOURS	MOS	10,000	6,000	250	3																																	
Change Interval																																																	
KM	MILES	HOURS	MOS																																														
10,000	6,000	250	3																																														

Section V - Specifications and Torque Values
C Series

Engine Lubricating Oil Recommendations
Page V-11

Oil Consumption

In addition to the information that follows, a service publication entitled Technical Overview of Oil Consumption is available, Bulletin 3379214-00.

Cummins defines "Acceptable Oil Usage" as outlined in the following table:

ACCEPTABLE OIL USAGE									
ANY TIME DURING COVERAGE PERIOD									
ENGINE FAMILY	HRS PER QT	HRS PER LITER	HOURS PER IMPERIAL QUART	MILES PER QUART	MILES PER LITER	MILES PER IMPERIAL QUART	KILOM PER QUART	KILOM PER LITER	KILOM PER IMPERIAL QUART
4B	10.0	10.6	12.0	400	425	475	650	675	775
6B	10.0	10.6	12.0	400	425	475	650	675	775
6C	10.0	10.6	12.0	400	425	475	650	675	775

Arctic Operation

If an engine is operated in ambient temperatures consistently below -23°C [-10°F] and there are no provisions to keep the engine warm when it is **not** in operation, use a synthetic CC/CE engine lubricating oil with adequate low temperature properties such as; 5W-20 or 5W-30.

The oil supplier **must** be responsible for meeting the performance service specifications.

⚠ Caution: The use of a synthetic base oil does not justify extended lubricating oil change intervals. Extended lubricating oil change intervals can decrease engine life due to factors such as; corrosion, deposits and wear.

Special "break in" engine lubricating oils are **not** recommended for new or rebuilt Cummins engines. Use the same type lubricating oil during the "break in" as that which is used in normal operation.

⚠ Caution: A sulfated ash limit of 1.85% has been placed on all engine lubricating oils recommended for use in Cummins engines. Higher ash lubricating oils may cause valve and/or piston damage and lead to excessive lubricating oil consumption.

For natural gas engines, a sulfated ash range of .03 to .85 mass percent is recommended. Cummins Engine Company, Inc., does **not** recommend the use of ashless lubricating oils for natural gas engines.

Additional information regarding lubricating oil availability throughout the world is available in the "E.M.A. Lubricating Oils Data Book for Heavy Duty Automotive and Industrial Engines." The data book may be ordered from the engine Manufacturers Association, One Illinois Center, 111 East Wacker Drive, Chicago, IL U.S.A. 60601. The telephone number is: (312) 644-6610.

Coolant Recommendations

ANTIFREEZE

SPECIFICATIONS - Use low silicate antifreeze which meets ASTM4985 test (GM6038M spec.) criteria.

CONCENTRATION - Antifreeze must be used in any climate for both freeze and boiling point protection. Cummins recommends a 50 percent concentration level (40 percent to 60 percent range) of ethylene glycol or propylene glycol in most climates. Antifreeze at 68 percent concentration provides the maximum freeze protection and must never be exceeded under any condition. Antifreeze protection decreases above 68 percent.

Ethylene Glycol

40% = -23°C [-10°F]

50% = -37°C [-34°F]

60% = -54°C [-65°F]

68% = -71°C [-90°F]

Propylene Glycol

40% = -21°C [-6°F]

50% = -33°C [-27°F]

60% = -49°C [-56°F]

68% = -63°C [-82°F]

CONCENTRATION TESTING - Antifreeze concentration must be checked using a refractometer (such as Fleet-guard Part No.CC2800). "Floating ball" type density testers or hydrometers are not accurate enough for use with heavy duty diesel cooling systems.

COOLANT CHANGE RECOMMENDATION - The coolant must be drained and replaced every 385,000 km [240,000 miles], 6,000 hours or 2 years (whichever occurs first) to eliminate buildup of harmful chemicals.

SUPPLEMENTAL COOLANT ADDITIVES

SUPPLEMENTAL COOLANT ADDITIVES (SCA) - Are recommended for all Cummins cooling systems. Antifreeze alone does not provide sufficient corrosion protection for heavy duty diesel engines.

DCA4 is the recommended SCA for all Cummins engines. Other brands can be used provided they provide adequate engine protection and do not cause seal or gasket degradation or corrosion/fouling.

SCA CONCENTRATION - The recommended concentration level of DCA4 is 1.5 units per 3.7 liter [1 U. S. gallon]. The DCA4 concentration must never exceed 3.0 units per 3.7 liter [1 U.S. gallon] nor fall below 1.2 units per 3.7 liter [1 U.S. gallon].

DCA4 FILTER CHANGE INTERVAL - Supplemental Coolant Additives deplete during normal engine operation. Cummins recommends that the level be maintained by installation of a service coolant filter on the engine at every 10,000 km [6,000 miles] 250 hours or 3 months interval.

COOLANT TEST KITS

DCA4 CONCENTRATION TESTS - As noted above, the primary method is to maintain proper DCA4 concentration levels by changing the service coolant filter at every 10,000 [6,000 mi] 250 hours or 3 months. Fleetguard DCA4 "dip strip" test Kit Part No. CC 2626 or Fleetguard Monitor C Part No. CC2700 must be used if testing is deemed necessary due to:

- addition of untreated make up coolant in excess of 5.7 liters [6 U.S. quarts] between maintenance intervals.
- troubleshooting of cooling system problems in the fleet (such as corrosion or seal leakage)
- An optional program in some fleets to monitor SCA levels to determine if maintenance intervals are acceptable.

NOTE: The practice of using a test kit to determine when to add or change the coolant filter is specifically not recommended. No other test kit (such as the Fleetguard Titration Test Kit Part No. 3300846-S or the 3825379-S) can be used on Cummins engines with DCA4.

DCA4 Unit Maintenance Guide

Fleetguard® Part No.	Cummins Part No.	DCA4 Units
DCA4 Liquid		
DCA 60L	3315459	4*
DCA4 Filter		
WF-2070	3318157	2
WF-2071	3315116	4
WF-2072	3318201	6
WF-2073	3315115	8
WF-2074	3316053	12
WF-2077	None	0

*If DCA60L is used, **do not** use a coolant filter that contains coolant additives. The combination of liquid and filter coolant additives will result in overconcentration.

DCA4 Maintenance Guide

Maintenance Intervals

Total Cooling System Capacity Liters [U.S. Gallons] (A)	Initial Charge (B)	3 Months
		250 Hours 10,000 KM (6,000 mi)
30 to 57 [6 - 12]	WF-2074	WF-2070

Notes:

- A. Consult the vehicle equipment manufacturer's maintenance information for total cooling system capacity.
- B. After draining and replacing the coolant, install the initial per charge coolant filter to provide the recommended level of DCA4 concentration.
- C. Change coolant filters at regular intervals to protect the cooling system.
- D. Check the coolant additive concentration regularly. Check cooling systems using DCA4 only with DCA4 Coolant Test Kit, Fleetguard® Part No. CC-2626.


Section V - Specifications and Torque Values
C Series

Filter Selection
Page V-17

Filter Selection


Lubricating Oil Filter

3825970 (LF3000) Standard Six Cylinder Applications



Fuel Filters

- A = Standard Filter used as secondary filter in dual filter applications.
- B = Fuel Water Separator Primary filter for dual filter applications.
- C = Fuel Water Separator used in single filter applications.



Engine Component Torque Values

Socket Or Wrench Size MM (Inch)		Torque N•m	[Ft-lb]
10	Aftercooler Mounting	24	[18]
8	Aftercooler Water Hose Clamp	5	[48 in-lb]
13	Alternator Link	24	[18]
13	Alternator Mounting Bolt (10-15 SI)	43	[32]
10	Alternator Support (Upper)	24	[18]
13	Belt Tensioner to Bracket	43	[32]
5 Hex	Belt Tensioner Bracket to Block	24	[18]
18	Vibration Damper	200	[148]
8	Crossover Clamp	5	[48 in-lb]
15	Exhaust Manifold	43	[32]
16	Exhaust Outlet Pipe Mounting	43	[32]
11	Exh Outlet Pipe, "V" Band Clamp	5	[48 in-lb]
10	Fan Bracket Mounting	24	[18]
13	Fan Hub	43	[32]
16	Fan Hub (60 mm Bolt Circle)	43	[32]
24	Flame Start Aid	40	[30]
19	Flywheel	137	[101]

Engine Component Torque Values (Continued)

Socket Or Wrench Size MM (Inch)		Torque N•m	[Ft-lb]
18	Flywheel Housing	77	[57]
(1/2)	Flywheel Housing Drain Plug	43	[32]
--	Front Gear Cover Cap	----Hand Tighten----	
15	Front Engine Support Mounting	112	[82]
17	Fuel Banjo Screw (in Filter Head)	24	[18]
10	Fuel Vent Screw in Banjo	9	[80 in-lb]
75-80	Fuel Filter	3/4 Turn After Contact	
19	Fuel Low Pressure Supply and return at Fuel Injection Pump....	24	[18]
10	Fuel Low Pressure Return at Filter Head	9	[80 in-lb]
24	Fuel Filter Adapter Nut	32	[24]
17	Fuel Line Fitting (High Pressure)	30	[22]
22	Fuel Injection Pump Drive Gear (A)	93	[68]
27	Fuel Injection Pump Drive Gear (MW)	105	[77]
30	Fuel Injection Pump Drive Gear (P)	165	[122]
24	Fuel Injection Pump Lock	15	[11]
15	Fuel Injection Pump Mounting Nut	43	[32]
10	Fuel Injection Pump to Bracket	24	[18]
10	Fuel Injection Pump Vent Screw (PES.MW)	5	[48 in-lb]
15	Fuel Solenoid Bracket	43	[32]
15	Fuel Injection Pump Support Bracket to Cylinder Block	43	[32]

Engine Component Torque Values (Continued)

Socket Or Wrench Size MM (Inch)		Torque N•m	[Ft-lb]
8	Fuel Solenoid Mounting	10	[84 in-lb]
10	Fuel Transfer Pump Mounting/Cover Plate	24	[18]
18	Engine Lifting Bracket	77	[57]
10	Gear Cover	24	[18]
10	Injector Fuel Drain Manifold	9	[80 in-lb]
10	Injector Retaining Capscrew	24	[18]
10	Intake Manifold Cover	24	[18]
118-131	Lubricating Oil Filter	3/4 Turn After Contact	
10	Lubricating Oil Cooler Cover	24	[18]
17	Lubricating Oil Pan Drain Plug	80	[60]
17	Lubricating Oil Pan Heater Plug	80	[60]
32	Lubricating Oil Pressure Regulator Valve	80	[60]
32	Lubricating Oil Thermostat	50	[37]
15	PTO Adapter	77	[57]
13	PTO Adapter Cover Plate A Drive	43	[32]
15	PTO Adapter Cover Plate B Drive	77	[57]
(3/4)	PTO Gear Nut A Drive	100	[74]

Engine Component Torque Values (Continued)

Socket Or Wrench Size MM (Inch)		Torque N•m	[Ft-lb]
(15/16)	PTO Gear Nut B Drive	134	[100]
(11/16)	PTO Flange Companion	85	[63]
14	Rocker Lever Nut	24	[18]
15	Starter Mounting (12 Point)	77	[57]
10	Tachometer Drive Retainer	3	[24 in-lb]
10	Thermostat Housing	24	[18]
T-25 Torx	Timing Pin Flange Mounting	5	[48 in-lb]
13	Turbine Housing	11	[96 in-lb]
11	Turbocharger Compressor Housing Clamp	6	[50 in-lb]
15	Turbocharger Mounting Nut	32	[24]
10	Turbocharger Drain Tube	24	[18]
16	Turbocharger Oil Supply (Both Ends)	15	[11]
8	Water Hose Clamps	5	[48 in-lb]
(3/8)	Water Inlet Plugs	34	[25]
13	Water Pump Mounting	24	[18]
15	Valve Cover	24	[18]
--	Valve Cover Oil Fill		Hand Tighten

Lubricants and Sealants - Engine Assembly

Use the sealants listed below or sealants containing equivalent properties.

Description	Sealing Method
1. Pipe Plugs	Precoated teflon or pipe sealer.
2. Gaskets	No sealant required.
3. Cup Plugs	Loctite™ 277 or Cummins Sealant 3375068.
4. O-rings	No sealant required.
5. Rear Camshaft Expansion Plug	Loctite™ 277 or Cummins Sealant 3375068.
6. Fuel Pump Studs	Loctite™ 242.
7. Turbocharger Drain (in block)	Loctite™ 277 or Cummins Sealant 3375068.
8. Dipstick Tube (in block)	Loctite™ 277 or Cummins Sealant 3375068.
9. Wet Flywheel Housing to Block	Three Bond Sealant 3823494
10. Rear Seal (in rear cover)	No sealant.
11. Timing Pin Housing Capscrews	No Sealant
12. Side Oil Fill	Loctite™ 277 or Cummins Sealant 3375068.

Section V - Specifications and Torque Values C Series

Lubricants and Sealants - Engine Assembly Page V-23

Use the lubricants listed below or lubricants containing equivalent properties.

Parts	Lubricant Required
Connecting Rod Bearings	Lubriplate 105
Main Bearings	Lubriplate 105
Camshaft Lobes and Journals	Lubriplate 105
Tappets	Lubriplate 105
Pistons	15W-40 Engine Lubricating Oil
Piston Rings	15W-40 Engine Lubricating Oil
Piston Pin	15W-40 Engine Lubricating Oil
Rocker Assemblies	15W-40 Engine Lubricating Oil
Push Tubes	15W-40 Engine Lubricating Oil + Lubriplate 105 in cup
Cylinder Liner O-Ring	15W-40 Engine Lubricating Oil

Capscrews - under head and on threads, as follows:

- Main Bearing Capscrews
- Cylinder Head Capscrews
- Connecting Rod Capscrews
- Flywheel Mounting Capscrews
- Damper Mounting Capscrews
- All Other Capscrews

15W-40 Engine Lubricating Oil
15W-40 Engine Lubricating Oil
15W-40 Engine Lubricating Oil
15W-40 Engine Lubricating Oil
15W-40 Engine Lubricating Oil
Preservative Lubricating Oil or
15W-40 Engine Lubricating Oil

Valve Stems and Seals
Lubricating Oil Pressure Regulator

15W40 Engine Lubricating Oil
15W-40 Engine Lubricating Oil

Section L - Service Literature

Section Contents

	Page
Additional Service Literature.....	L-2
Service Literature Ordering Location	L-3

Additional Service Literature

The following publications can be purchased by filling in and mailing the Service Literature Order Form:

Bulletin No.	Title Of Publication
3666003	C Series Troubleshooting and Repair Manual (1991 Engines)
3666008	C Series Engine Shop Manual (1991 Engines)
3666021	C Series Specifications Manual (1991 Engines)
3810354	C Series Operation & Maintenance Manual - Generator Set
3810428	C Series Operation & Maintenance Manual - Power Unit
3810327	C Series Standard Repair Times Manual

Parts Catalogs

3884251	6CT/CTA-8.3 - Automotive
3884303	6CTA-8.3 Automotive charge air cooled
3884236	6C/CT/CTA-8.3 - Construction
3884253	6CT/CTA-8.3 - Generator Drive
3884311	6C-8.3 - Power Unit
3884312	6CT-8.3 - Power Unit
3884313	6CTA-8.3 - Power Unit

Index Page X-1

About the Manual	i-3	Air Cylinders	C-2
Additional Service Literature	L-2	Air Heaters	C-2
Aftercooler and Gasket	A-60	Air Starting Motors	C-2
Replacement	A-60	Alternators	C-2
Air Cleaner	4-13	Auxiliary Brakes	C-3
Restriction	4-13	Belts	C-3
Air Compressor	7-9	Catalytic Convertors	C-3
Air Compressor Discharge Inspection	7-10	Clutches	C-3
Air Compressor Intake Inspection	7-12	Coolant Heaters	C-3
Inspection	7-9	Drive Plates	C-4
Air Intake System	4-11	Electric Starting Motors	C-4
Charge Air Cooler	4-11	Engine Protection Controls	C-4
Inspection	4-11	Fan Clutches	C-4
Air System	D-10	Fans	C-4
Air System Repair Summary	A-56	Filters	C-5
Alternator	A-89	Flexplates	C-5
Replacement	A-89	Fuel Warmers	C-5
Antifreeze Concentration	5-8	Gauges	C-5
Checking	5-8	Governors	C-6
Belt Tensioner	A-7	Hydraulic and Power Steering Pumps	C-6
Replacement	A-7	Oil Heaters	C-6
C Series Engine Maintenance Schedule	2-4	Torque Converters	C-6
Page References for Maintenance Instructions	2-5	Coolant Additive Concentration	5-8
California Emission Control System Warranty	W-39	Checking	5-8
Capscrew Markings and Torque Values	V-25	Coolant Filter/DCA4 Corrosion Resistor Cartridge	5-9
Capscrew Markings and Torque Values - Metric	V-26	Coolant Filter	5-10
Charge Air Cooler	A-64	Replacement	5-10
Intake Manifold Pressure - Check	A-64	Coolant Level	3-4
Intake Manifold Temperature - Checking	A-64	Checking	3-4
Leak Check	A-66	Coolant Recommendations	V-13 , V-14
Cold Weather Starting Aids	1-6	DCA4 Unit Maintenance Guide	V-15
Cold Weather Starting With Starting Fluid	1-7	Coolant System	D-8 , D-9
Using Starting Fluid Without Metering Equipment	1-7	Coolant Thermostat	A-15
With Mechanical Or Electrical Metering Equipment	1-7	Replacement	A-15
Component Manufacturers' Addresses	C-2	Cooling Fan	3-6
Air Compressors	C-2	Inspection	3-6

Cooling System Maintenance	7-3
Coolant Draining	7-3
Coolant System Filling	7-7
Coolant System Flushing	7-4
Cooling System Repair Summary	A-6
Cummins Warranty - Australia Automotive	W-2
Cummins Warranty - U.S.A./Canada Automotive	W-12
Cummins Warranty - U.S.A./Canada Bus and Coach	W-17
Cummins Warranty - U.S.A./Canada Fire Truck	W-5
Cummins Warranty - U.S.A./Canada Industrial	W-34
Cummins Warranty - U.S.A./Canada School Bus/	
Recreational Vehicles	W-23
Cummins Warranty - Worldwide Generator Drive	W-29
Definition of Terms	i-12
Distributors and Branches - Australia	S-22
Distributors and Branches - Canada	S-19, S-20
Distributors and Branches - New Zealand	S-24
Distributors and Branches - United States S-5, S-6, S-7, S-8, S-9	
S-10, S-11, S-12, S-13, S-14, S-15, S-16, S-17, S-18	
Division and Regional Offices	S-4
Drive Belt	3-5
Inspection	3-5
Replacement	A-7
Drive Belt Tension	6-10
Checking	6-10
Drive Belt, Tensioner Bearing and Fan Hub	6-11
Inspection	6-11
Electrical System Repair Summary	A-87
Emergency	S-2
Engine Component Torque Values	V-18
Engine Diagrams	E-9
Engine Identification	E-2
Cummins Engine Nomenclature	E-3
Engine Dataplate	E-2
Engine Lubricating Oil Recommendations	V-8
Arctic Operation	V-12

Lubricating Oil Viscosity Recommendations	V-8
Oil Consumption	V-11
Engine Operating Range	1-10
Engine Shut-down Procedure	1-10
Exhaust Manifold and Gaskets	A-75
Replacement	A-75
Fan Pulley	A-9
Replacement	A-9
Filter Selection	V-17
Fuel Filters	V-17
Lubricating Oil Filter	V-17
Fuel Drain Manifold	A-32
Replacement	A-32
Fuel Filter	5-3
Replacement	5-3
Fuel Filter Head Adapter	A-26
Replacement	A-26
Fuel Injection Pump	A-40
Replacement	A-40
Fuel Recommendations/Specifications	V-6
Fuel Shutoff Solenoid	A-37
Replacement	A-37
RQVK Governor Fuel Shutoff Solenoid	A-39
RSV Governor Fuel Shutoff Solenoid	A-38
Fuel System	D-3
Bleeding	5-5
Fuel System Components	A-24
Cleaning	A-24
Fuel System Repair Summary	A-23
Fuel Transfer Pump	A-27
Replacement	A-27
Fuel-Water Separator	3-3
Draining	3-3
General Information	2-2
General Operating Instructions	1-2
General Safety Instructions	i-10

Important Safety Notice	i-10
General Specifications	E-5
ELECTRICAL SYSTEM	E-8, V-5
High Pressure Fuel Lines	A-29
Replacement	A-29
Venting	A-31
High Pressure Lines	5-7
Venting	5-7
How to Use the Manual	i-4
Illustrations	i-9
Injection Pump - Idle Speed Adjustment	A-53
RQV and RQVK Governor	A-55
RSV Governor	A-53
Injection Pump Dataplate	E-4
Injectors	A-33
Replacement	A-33
Intake Air Piping	A-57
Replacement	A-57
Intake Manifold Cover and Gasket	A-58
Replacement	A-58
Low Pressure Fuel Line	A-24
Replacement	A-24
Low Pressure Lines and Fuel Filter(s)	5-6
Venting	5-6
Lubricants and Sealants - Engine Assembly	V-22
Lubricating Oil and Filter	4-5
Changing	4-5
Lubricating Oil and Filter Change Interval	4-3
Lubricating Oil Cooler Element and Gasket	A-82
Replacement	A-82
Lubricating Oil Level	3-3
Checking	3-3
Lubricating Oil Pressure Regulator, Valve and Spring	A-79
Replacement	A-79
Lubricating Oil System	D-4
Lubricating Oil System Repair Summary	A-78

Lubricating Oil Thermostat	A-80
Replacement	A-80
Lubrication for the Overhead	D-7
Lubrication for the Power Components	D-6
Lubrication for the Turbocharger	D-5
Operating the Engine	1-9
Problem Solving	S-3
Repair Procedures	A-4
Repair Tools Required	A-5
Routine	S-2
Service Literature Ordering Location	L-3
Starting Motor	A-88
Replacement	A-88
Starting Procedure	1-2
Shutters	1-5
Starting Procedure Matrix	1-3
Winterfronts	1-5
Starting Procedure After Extended Shutdown or Oil Change	1-8
Symbols	i-5
To The Owner and Operator	i-2
Tool Requirements	2-3
Troubleshooting Procedures and Techniques	T-3
Troubleshooting Symptoms Charts	T-3
Alternator Not Charging or Insufficient Charging	T-32
Contaminated Coolant	T-18
Contaminated Lubricating Oil	T-19
Coolant Loss	T-16
Coolant Temperature Above Normal	T-14
Coolant Temperature Below Normal	T-17
Engine Cranks, But Will Not Start - No Smoke From Exhaust... ..	T-6
Engine Difficult to Start or Will Not Start (Exhaust Smoke Present)	T-5
Engine Misfiring	T-27
Engine Starts But Will Not Keep Running	T-7
Engine Surges at Idle	T-10
Engine Will Not Crank or Cranks Slowly	T-4

Index
Page X-4

Engine Will Not Reach Rated Speed When Loaded	T-23
Engine Will Not Shut Off	T-8
Excessive Engine Noises	T-31
Excessive Fuel Consumption	T-29
Excessive Vibration	T-30
Exhaust Smoke Excessive Under Load	T-21
Exhaust White Smoke Excessive	T-22
Fuel Knock	T-28
Fuel or Oil Leaking from Exhaust Manifold	T-20
Low Power	T-24
Lubricating Oil Loss	T-13
Lubricating Oil Pressure Low	T-11
Lubricating Oil Pressure Too High	T-12
Rough Idle, Warm Engine	T-9
Turbocharger	A-66
Replacement	A-66
Valve Clearance	6-3
Adjusting	6-3
Vibration Damper	7-8
Inspection	7-8
Water Pump	A-10
Replacement	A-10



Operation and Maintenance Manual C Series Engines

U.S.A., Canada, Australia,
New Zealand, and Puerto Rico



Copyright © 1993
Cummins Engine Company, Inc.
All rights reserved

Bulletin No. 3810248-08
Printed 8/93

Foreword

This manual contains information for the correct operation and maintenance of your Cummins engine. It also includes important safety information, engine and systems specifications, troubleshooting guidelines, and listings of Cummins Authorized Repair Locations and component manufacturers.

Keep this manual with the equipment. If the equipment is traded or sold, give the manual to the new owner.

The information, specifications, and recommended maintenance guidelines in this manual are based on information in effect at the time of printing. Cummins Engine Company, Inc. reserves the right to make changes at any time without obligation. If you find differences between your engine and the information in this manual, contact your local Cummins Authorized Repair Location.

The latest technology and the highest quality components were used to produce this engine. When replacement parts are needed, we recommend using only genuine Cummins or ReCon® exchange parts. These parts can be identified by the following trademarks:



Note: Warranty information is located in Section W. Make sure you are familiar with the warranty or warranties applicable to your engine.